

This file is available for free download at <http://www.iluvmyrx7.com>

This file was not scanned to deprive Mazda of any money - it was scanned due to the rareness of the original manuals and the overwhelming need of the RX-7 owner to have this information so that they can accurately troubleshoot problems. Perhaps if Mazda's dealerships could support the Rotary Engine it wouldn't be so necessary for the owners to do so.



Many thanks to Lenny Terris for scanning this.

Before beginning any service procedure, refer to the 1994 RX-7 Body Electrical Troubleshooting Manual; see section S for air bag system service warnings and section J1 for audio antitheft system alarm conditions.


D

LUBRICATION SYSTEM

INDEX	D - 2
OUTLINE	D - 3
SPECIFICATIONS	D - 3
TROUBLESHOOTING GUIDE	D - 4
OIL PRESSURE	D - 5
PREPARATION	D - 5
INSPECTION	D - 5
ENGINE OIL	D - 6
INSPECTION	D - 6
REPLACEMENT	D - 6
OIL FILTER	D - 7
REPLACEMENT	D - 7
OIL COOLER	D - 8
REMOVAL / INSTALLATION	D - 8
OIL PAN	D - 9
PREPARATION	D - 9
REMOVAL / INSTALLATION	D - 10
OIL PRESSURE CONTROL VALVE	D - 13
REMOVAL / INSTALLATION	D - 13
METERING OIL PUMP	D - 14
PREPARATION	D - 14
INSPECTION	D - 15
OIL PUMP	D - 17
DISASSEMBLY/ASSEMBLY	D - 17
INSPECTION	D - 18

D

INDEX



- 1. Oil filter
Replacement page D-7
- 2. Oil cooler
Removal / Installation page D-8


- 3. Oil pan
Removal / Installation page D-10
- 4. Metering oil pump
Inspection page D-14

OUTLINE

SPECIFICATIONS

Item		Engine model	13B Turbo	
Lubrication system			Force-fed	
Oil pump	Type		Trochoid	
	Number of rotors		2	
	Diameter × width of rotor	mm {in}	50 × 17.5 {1.97 × 0.69}	
Control valve relief pressure		kPa{kgf·cm ² , psi}	1080 {11.0, 156}	
Oil cooler	Type		Air-cooled, with bypass valve	
	Relief temperature	°C {°F}	60–65 {140–149} or below	
	Relief pressure differential	kPa{kgf·cm ² , psi}	349 {3.56, 50} at 60°C {149°F}	
Regulator valve relief pressure		kPa{kgf·cm ² , psi}	780 {8.0, 110}	
Oil filter	Type		Full-flow, paper element	
	Relief pressure differential	kPa{kgf·cm ² , psi}	98 {1.0, 14}	
Eccentric shaft bypass valve relief temperature		°C {°F}	60 {140} or below	
Engine oil	Total (dry engine)	L {US qt, Imp qt}	4.9 {5.2, 4.3} ... except R1 model 5.4 {5.7, 4.8} ... R1 model	
	Oil replacement	L {US qt, Imp qt}	3.6 {3.8, 3.2}	
	Oil replacement (with oil filter)	L {US qt, Imp qt}	3.8 {4.0, 3.3}	
	Oil filter	L {US qt, Imp qt}	Factory installed	0.19 {0.20, 0.17}
			Service part	0.17 {0.18, 0.15}
	Grade		API Service SG, SH (ECII) ILSAC (Mineral oil only)	

Recommended SAE Viscosit



Anticipated ambient temperature range before the succeeding oil change, °C {°F}

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Action	Page
Engine hard starting	Improper oil Insufficient oil	Replace Add oil	D-6 D-6
Excessive oil consumption	Malfunction of metering oil pump mechanical component Faulty oil nozzle Oil leakage	Inspect Inspect Repair	D-14 D-17 —
Oil leakage	Loose drain plug or damaged washer Faulty seal at oil pan Damaged front cover Loose front cover bolt or oil pan bolt Damaged sealing rubber, O-ring, or front cover gasket Malfunction of oil seal Loose oil filter Loose or damaged oil level sensor or oil pressure gauge Damaged oil cooler or oil cooler hose Damaged oil tube	Tighten or replace Repair Replace Tighten Replace Replace Tighten Tighten or replace Replace Replace	D-9 D-9 — — — — D-7 — D-8 —
Oil pressure drop*	Oil leakage Insufficient oil Worn or damaged oil pump gear Clogged oil strainer Malfunction of oil pressure control valve Malfunction of oil pressure regulator valve Clogged oil filter Malfunction of eccentric shaft bypass valve Excessive oil clearance between eccentric shaft and main bearing	Repair Add oil Refer to Section C Clean Replace Replace Replace Refer to Section C Refer to Section C	— D-6 — — D-13 D-9 D-7 — —
Oil pressure gauge does not work	Oil pressure drop Malfunction of oil pressure gauge unit Malfunction of electrical system	As described above Refer to Section T Refer to Section T	D-5 — —
Oil level warning indicator illuminates when engine is running	Insufficient oil Malfunction of oil level sensor Malfunction of electrical system	Add oil Refer to Section T Refer to Section T	D-6 — —
Poor acceleration	Malfunction of metering oil pump electrical component	Inspect	D-14
Rough Idle	Malfunction of metering oil pump electrical component	Inspect	D-14


* Oil pressure becomes low when the engine is cold because the eccentric shaft bypass valve operates.

OIL PRESSURE


Warning

- Continuous exposure with USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.


PREPARATION**SST**

<p>49 0187 280</p> <p>Gauge, oil-pressure</p> 	<p>For inspection of oil pressure</p>
---	---

D

**INSPECTION**


1. Disconnect the connector and remove the oil pressure sensor.



2. Install the SST.
3. Start the engine and let it warm up to operating temperature.
4. Run the engine at 3,000 rpm and note the gauge reading.

Oil pressure: 340 kPa {3.5 kgf·cm², 50 psi} min

5. If the pressure is not as specified, check for the cause and repair. (Refer to Troubleshooting Guide.)
6. Remove the SST.



7. Apply sealant to the oil pressure sensor threads. Do not allow sealant in the pressure sensor hole.
8. Install the oil pressure sensor.


Tightening torque:

11–15 N·m {1.1–1.6 kgf·m, 8–11 ft·lbf}

9. Connect the sensor connector.

D

ENGINE OIL



ENGINE OIL

INSPECTION

1. Be sure the vehicle is on level ground.
2. Warm up the engine to normal operating temperature and stop it.
3. Wait for five minutes.
4. Remove the dipstick and check the oil level and condition.
5. Add or replace oil as necessary.

Note

- The distance between the L and F marks on the dipstick represents 1.7 L {1.8 US qt, 1.5 Imp qt}.

REPLACEMENT

Warning

- When the engine and the oil are hot, they can badly burn. Don't burn yourself with either.

1. Warm up the engine to the normal operating temperature and stop it.
2. Remove the oil filler cap and the oil drain plug.
3. Drain the oil into a container.
4. Install a new gasket and the drain plug.

Tightening torque:

30–41 N·m {3.0–4.2 kgf·m, 22–30 ft·lb}



5. Refill the engine with the specified type and amount of engine oil.


Oil capacity:

L {US qt, Imp qt}

Total (dry engine)	4.9 {5.2, 4.3}...except R1 model 5.4 {5.7, 4.8}...R1 model
Engine oil replacement	3.6 {3.8, 3.2}
Engine oil replacement (with oil filter)	3.8 {4.0, 3.3}

6. Refit the oil filler cap.
7. Run the engine a few minutes and stop it.
8. Recheck the oil level and add oil if necessary.



**OIL FILTER****REPLACEMENT**

1. Remove the oil filter by using the oil filter wrench.
2. Using a clean rag, wipe the mounting surface of the engine.
3. Apply a small amount of clean engine oil to the rubber seal of the new filter.
4. Install the oil filter and tighten it until the rubber seal contacts the base, and then tighten the filter an additional 1-1/6 turns by hand.
5. Start the engine and inspect for leaks around the filter seal.
6. Stop the engine and check the oil level; add oil if necessary.

Note

- The factory installed oil filter and the service part filter are different.

Service oil filter capacity:

0.17 L {0.18 US qt, 0.15 Imp qt}

D

OIL COOLER


REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.

Note

(In case of two oil cooler are equipped)

- LH oil cooler is shown.
Remove / install RH oil cooler in same procedure.




1. Light bezel
2. Brake pipe air duct
3. Oil cooler hoses

Removal Note page D-9

4. Oil cooler

Removal Note page D-9


5. Air duct (oil cooler)



Removal Note

Oil cooler hose

Remove the clip and disconnect the oil cooler hose, using a drain pan to catch the oil.



Oil cooler

1. Remove the light bezel.
2. Remove the mounting bracket nuts.
3. Remove the oil cooler.

Steps After Installation

Fill the engine with the specified amount and type of engine oil. (Refer to page D-6.)

OIL PAN

PREPARATION

SST


<p>49 G017 5A0 Support, engine</p> 	<p>For support of engine</p>	<p>49 G017 501 Bar (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>
<p>49 G017 502 Support (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>	<p>49 G017 503 Hook (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>

D

OIL PAN


REMOVAL / INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the undercover.
3. Drain the engine oil.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal, referring to **Installation Note**.




1. Undercover
2. Stabilizer
3. Engine mount bracket
Removal Note page D-11
4. Steering gear box

5. Crossmember
Removal Note page D-11
6. Oil pan
Removal Note page D-11
Installation Note page D-12




Removal Note
Engine mount bracket

1. Assemble the **SST** and connect the hook to the front engine hanger.




2. Remove the engine mounting nuts.
 3. Turn the bolt of the **SST** clockwise to lift the engine.



Crossmember

1. Remove the power steering oil hose bracket from the crossmember.
 2. Remove the bolts and nuts (arrows) and the crossmember.




Oil pan

1. Remove the engine mount brackets from the engine.
 2. Disconnect the oil level sensor connector and remove it from the harness bracket.
 3. Remove the oil pan mounting bolts.

Caution


- Pry tools can easily scratch the oil pan contact surfaces. Prying off the oil pan can also easily bend the oil pan flange. Refer to the following instructions before removing the oil pan.



4. Insert a screwdriver only between the points shown in the figure to pry the oil pan loose.

D

OIL PAN




Installation Note

Oil pan

1. Remove all foreign material from the oil pan contact surfaces.

Caution

- If the bolts are reused, remove the old sealant from the bolt threads. Tightening bolts with old sealant on them may cause cracking inside the bolt holes.




2. Apply silicone sealant to the contact surfaces of the oil pan and the engine side of the new gasket.
3. Install the oil pan within five minutes of applying the sealant.

Tightening torque:

8.9–11.7 N·m {90–120 kgf·cm, 79–104 in·lbf}

Steps After Installation


Fill the engine with the specified amount and type of engine oil. (Refer to page D-6.)



OIL PRESSURE CONTROL VALVE

REMOVAL / INSTALLATION

1. Remove the parts in the following order.
 - (1) Oil pan (Refer to page D-9.)
 - (2) Cap bolt and spring
 - (3) Control plunger
2. Install in the reverse order.
3. Check the engine for oil leakage and check the oil level.



INSPECTION

1. Check each part for damage and scoring. Replace if necessary.
2. Measure the free length of the spring, and if necessary, replace it.



Free length: 73.0 mm {2.87 in}

D

METERING OIL PUMP

METERING OIL PUMP

PREPARATION SST

<p>49 H018 9A1 Self-Diagnosis Checker</p> 	<p>For diagnosis of metering oil pump system</p>	<p>49 B019 9A0 System Selector</p> 	<p>For diagnosis of metering oil pump system</p>
---	--	---	--

Malfunctions related to the metering oil pump may be described as electrical component problems and mechanical component problems.

Electrical Component Related Problem

1. Check for service codes by using the SST. (Refer to section F.)
2. If service code No. 20, 26, 27 or 37 appears, check the metering oil pump following the diagnosis chart below.

Diagnosis Chart


Service Code No.	Possible Cause	Action
20 (Metering oil pump position sensor)	<ul style="list-style-type: none"> ● Open or short circuit in position sensor wiring ● Open or short circuit in wiring between powertrain control module and position sensor ● Loose connection of position sensor or powertrain control module 	Perform Inspection 2 (page D-16)
26 (Metering oil pump control system)	<ul style="list-style-type: none"> ● Open or short circuit in wiring between powertrain control module and stepping motor ● Loose connection of metering oil pump or powertrain control module ● Damaged stepping motor ● Insufficient powertrain control module voltage 	Perform Inspection 1 (page D-15)
27 (Metering oil pump control system)	<ul style="list-style-type: none"> ● Open or short circuit in wiring between powertrain control module and stepping motor ● Loose connection of metering oil pump or powertrain control module ● Damaged stepping motor ● Position sensor inaccurate ● Insufficient powertrain control module voltage 	Perform Inspection 1 (page D-15)
37 (Battery positive voltage drop)	<ul style="list-style-type: none"> ● Malfunction of charging system 	Refer to Section G

Control Module Terminal

4Y	4W	4U	4S	4Q	4O	4M	4K	4I	4G	4E	4C	4A	3D	3M	3K	3I	3G	3E	3C	3A	2K	2I	2G	2E	2C	2A	U	S	Q	O	M	K	I	G	E	C	A
4Z	4X	4V	4T	4R	4P	4N	4L	4J	4H	4F	4D	4B	3P	3N	3L	3J	3H	3F	3D	3B	2L	2J	2H	2F	2D	2B	V	T	R	P	N	L	J	H	F	D	B

INSPECTION


1. Metering oil pump control system



D

METERING OIL PUMP


2. Metering oil pump position sensor



Mechanical Component Related Problem

Excessive oil consumption may be caused by a metering oil pump malfunction.

Before replacing the metering oil pump, refer to "Oil leakage" in the Troubleshooting Guide (page D-4) and perform the electrical component inspection (pages D-15 and D-16).




Oil nozzle

1. Remove the oil nozzles from the rotor housing and the intake manifold.
2. Verify that air passes in only one direction as shown. If not so, replace the oil nozzle.

OIL PUMP

DISASSEMBLY / ASSEMBLY


1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- | | | |
|---------------------|----------------------|----------------------|
| 1. Snap ring | 5. Screw | 9. Front inner rotor |
| 2. Rear outer rotor | Assembly Note | Assembly Note |
| Assembly Note | page D-19 | page D-18 |
| page D-18 | 6. Body | 10. Key |
| 3. Rear inner rotor | 7. Center plate | 11. Shaft |
| Assembly Note | 8. Front outer rotor | |
| page D-18 | Assembly Note | |
| 4. Key | page D-18 | |

D


OIL PUMP



INSPECTION


1. Inspect the oil pump parts for wear and damage.
Replace as necessary.
2. Measure the clearance between the lobes of rotors by using a feeler gauge.

Standard clearance:
0.03–0.12 mm {0.0012–0.0047 in}
Maximum: 0.15 mm {0.0059 in}




3. Measure the clearance between the outer rotor and the pump body.

Standard clearance:
0.20–0.25 mm {0.0079–0.0098 in}
Maximum: 0.30 mm {0.0118 in}



4. Inspect the side clearance of the rotors.
 - (1) Using a straightedge and a feeler gauge, measure the depth of the rotor in the pump body.




- (2) Measure the depth of the rotor sliding surface from the pump mounting surface.
- (3) Add these two depth to obtain the side clearance.
- (4) If not as specified, grind or replace the pump body.

Standard end clearance:
0.03–0.125 mm {0.0012–0.0049 in}
Maximum: 0.15 mm {0.0059 in}

Assembly Note


Outer rotor and inner rotor

Install the front and rear outer and inner rotors so that the tally marks on the rotors face the front housing.



OIL PUMP

D



Screw

To prevent the screw from loosening, stake it after installation.