

This file is available for free download at <http://www.iluvmyrx7.com>



www.iluvmyrx7.com

PART NUMBER INDEX

This index is listed in the following sequence.

GENERAL PARTS

EXAMPLE

- 1 Model/Type
Third, in the sequence of model/type (1st-4th digits)
- 2 Group
First, in the sequence of group (5th & 6th digits)
- 3 Part
Second, in the sequence of part (7th-9th digits)

INDEX DES NOMBRES DE PIÈCES

Cet index a été composé selon la séquence suivante.

PIÈCES GÉNÉRALES

EXEMPLE

- 1 Modèle/type
Troisièmement, séquence du modèle/type (1er à 4ème chiffres)
- 2 Groupe
Premièrement, séquence du groupe (5ème et 6ème chiffres)
- 3 Pièce
Deuxièmement, séquence de la pièce (7ème à 9ème chiffres)

NUMERO INDICE DE PIEZA

Este índice se ordena en la siguiente secuencia.

PIEZAS GENERALES

EJEMPLO

- 1 Tipo de modelo
Tercero, en la secuencia de tipo de modelo (entre las cifras 1ro-4to lugar)
- 2 Grupo
Primero, en la secuencia de grupo (las cifras en 5to y 6to lugar)
- 3 Pieza
Segundo, en la secuencia de pieza (entre las cifras 7mo-9no lugar)

TEILENUMMERN

Die Teilenummern setzen sich wie folgt zusammen.

ALLGEMEINE TEILE

BEISPIEL

- 1 Modell/Typ
Angabe des Modells bzw. Type (1. bis 4. Ziffern)
- 2 Baugruppe
Angabe der Baugruppe (5. und 6. Ziffer)
- 3 Teil
Angabe des Teils (7. bis 9. Ziffer)

① ② ③
| | |
B A O 1 6 0 3 5 0

STANDARD PARTS

Standard Parts are listed in numerical sequence after General Parts.
(Note: Those parts which do not have D-Code are not listed in the index.)

PIÈCES STANDARD

Les pièces standard sont énumérées selon une séquence numérique, après les pièces générales.
(Remarque: Les pièces qui ne possèdent pas de code D ne sont pas mentionnées dans cet index.)

PIEZAS NORMALES

Las piezas normales se numeran secuencialmente después de las Piezas generales.
(Note: Las piezas que no tienen un código D no están en el índice.)

STANDARDTEILE

Die Standardteile sind nach den allgemeinen Teilen mit fortlaufender Numerierung aufgeführt.
(Hinweis: Teile ohne D-Code sind nicht aufgeführt.)

PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

R507-17-221	1-J7	0221-17-441A	1-D8	PN16-18-W27	1-I8	8BF1-18-140A	1-G8	BV65-19-090G	1-E9	BV11-19-404	1-L9	BV45-19-561	1-E11
0317-17-225	1-J7	1011-17-443	1-G7	NSA1-18-W35	1-J8	JF03-18-141A	3-K8	BV65-19-100	1-E9	BV11-19-405	1-L9	BV45-19-561A	1-E11
R527-17-230	1-J7		1-J9	NS36-18-W36	1-I8	NSA1-18-180A	1-G8	BV11-19-201	1-E9	BV11-19-406	1-L9	BV11-19-567	1-E11
R523-17-240	1-J7	R514-17-450	1-G7	NSA1-18-W45	1-I8	NSA1-18-190A	1-G8	BV11-19-202	1-E9	BV11-19-429	3-J6	BV46-19-570	1-E11
F401-17-243A	1-J7	R514-17-450A	1-G7	NSA1-18-W50	1-I8	NSA1-18-211	3-H6	BV11-19-203	1-E9	BV11-19-431	1-J11	BV45-19-571	1-E11
R535-17-250	1-K7	R504-17-455	1-G7	NSA1-18-W51	1-I8	NSA1-18-221	3-H6	BV11-19-204	1-E9	BV11-19-434	1-J11	BV11-19-572	1-C11
R503-17-26Y	1-K7	R522-17-461	1-G7	NSA1-18-W60	1-I8	NSA1-18-222	3-H6	BV11-19-205	1-E9	BV11-19-437	1-L9	BV11-19-572A	1-D11
F504-17-26Y	1-K7	R522-17-461A	1-G7	JE48-18-W70	1-I8	NSA1-18-251	1-G8	BV11-19-206	1-E9	BV65-19-437	1-L9	BV11-19-573	1-D11
R523-17-260	1-K7	Q398-17-462A	1-E8	B3C7-18-W77	1-I8	NSA1-18-300A	1-I8	BV11-19-207	1-E9	BV65-19-440	1-J11	BV11-19-573A	1-D11
W501-17-263A	1-K7	R504-17-470	1-E8	NSA1-18-W80	1-J8	NSA1-18-360B	1-G8	BV65-19-210	1-E9	BV65-19-443	1-J11	BV45-19-588	1-E11
G401-17-264	1-K7	R504-17-470A	1-E8	NF01-18-X00A	1-L8	NSA1-18-381	1-G8	BT40-19-216	1-E9	BV65-19-444	3-J6	BV11-19-587	1-E11
R501-17-264	1-K7	M501-17-474	1-G7	NSA1-18-X00	1-L8	NSA2-18-381	1-H8	BV65-19-220	1-E9	BV65-19-444A	3-J6	BV11-19-590	1-E11
M502-17-265C	1-K7	Q303-17-474	1-E8	E356-18-X01	1-M8	NSA1-18-397	1-H8	BV60-19-221	1-E9	BV11-19-450	1-J11	BV11-19-593	1-E11
R503-17-265B	1-K7	M503-17-475	1-H7	F210-18-X01	1-M8	NF01-18-400B	1-L8	BV65-19-221	1-E9	BV11-19-451	1-M10	BV11-19-595	1-E11
R514-17-265B	1-K7	R503-17-476	1-H7	NF01-18-X05	1-M8	NSA1-18-400	1-L8	BV65-19-240	1-E9	BV11-19-453	1-M10	BV11-19-601	1-E11
R507-17-268	1-K7	M513-17-480A	1-E8	NS326-18-X05	1-M8	JE15-18-51X	3-T6	BV11-19-241	1-E9	BV11-19-454	1-C11	BV11-19-602	1-E11
R513-17-270A	1-K7	R503-17-481	1-E8	G401-18-X06	1-N8	KL01-18-51X	3-T6	BV11-19-242	1-E9	BV11-19-454A	1-D11	BV11-19-603	1-E11
0884-17-274	1-K7	G540-17-482B	1-H7	NF01-18-X10	1-N8	AM15-18-520A	1-C9	BV11-19-247	1-E9	BV11-19-456	1-C11	BV11-19-604	1-F11
0884-17-275B	1-K7	M505-17-482	1-E8	NSA1-18-X10	1-N8	E364-18-520B	1-C9	BV11-19-255	1-F9	BV11-19-456A	1-D11	BV11-19-605	1-F11
3648-17-275A	1-K7	R507-17-495	1-H7	NF01-18-X20	1-M8	N251-18-520B	1-C9	BV50-19-255	1-D10	BV11-19-457	1-C11	BV11-19-606	1-F11
0839-17-276	1-K7	R507-17-510A	1-E8	NS18-18-X20	1-L8	FE50-18-522	1-C9	BV11-19-256	1-F9	BV11-19-457A	1-D11	BV11-19-607	1-F11
0839-17-277	1-L7	M501-17-515	1-D8	NS27-18-X20	1-M8	NSA1-18-591D	1-C9	BV11-19-257	1-F9	BV11-19-458	1-C11	BV46-19-6F1	1-F11
0839-17-278	1-L7	R503-17-520A00	1-E8	NS18-18-X25	1-N8	NSA1-18-591E	1-C9	BV11-19-381	1-L10	BV11-19-458A	1-D11	BV65-19-6M6	1-G11
R505-17-281	1-L7	R503-17-520B00	1-E8	NS26-18-X30	1-L8	NSA1-18-593A	1-C9	BV41-19-382	1-G11	BV11-19-459	1-C11	BV45-19-601	1-G11
R502-17-283	1-L7	R501-17-523	1-H7	NF01-18-X35	1-M8	NSA1-18-593B	1-C9	BV45-19-384	1-L10	BV11-19-459A	1-D11	BV65-19-601	1-G11
0839-17-287	1-L7	M501-17-530A	1-H7	NF01-18-X40	1-M8	NSA2-18-593A	1-C9	BV11-19-385A	1-L10	BV11-19-475	1-L9	BV11-19-603	1-F11
0839-17-288	1-L7	0884-17-530	1-D9	NS26-18-X40	1-M8	NSA1-18-701	3-L6	BV11-19-386	1-L10	BV11-19-476	1-L9		1-H11
R501-17-295	1-L7	R505-17-540	1-H7	NF01-18-X50	1-M8	F285-18-741	1-J5	BV11-19-382	1-J9	BV11-19-480	1-M10	BV11-19-605	1-F11
R501-17-299	1-L7	R507-17-540	1-H7	F225-18-X56	1-L8	NSA1-18-741	1-F5	BV11-19-383	1-J9	BV11-19-484	1-M10	BV35-19-605	1-F11
R525-17-301	1-L7	M501-17-543A	1-H7	NF01-18-X56	1-L8	NSA7-18-741	1-J5	BV11-19-387	1-J9	BV11-19-497	1-M10	BV45-19-609	1-H11
R504-17-302A	1-L7	R503-17-543	1-H7	NS26-18-X57	1-N8	NS90-18-741	1-K5	BV11-19-388	1-J9	BV11-19-498	1-M10	BV56-19-610	1-H11
0821-17-303	1-L7	R505-17-550	1-H7	F214-18-X60A	1-L8	NSA1-18-744	1-K5	BV65-19-380	1-M10	BV45-19-499	1-M10	BV11-19-613	1-H11
R501-17-304	1-L7	R502-17-551	1-H7	NF01-18-X60A	1-L8	JE16-18-811	3-L6	BV11-19-383	1-K9	BV11-19-580	1-M10	BV45-19-613	1-H11
0839-17-305B	1-L7	R501-17-552	1-E8	NS26-18-X62A	1-L8	NF01-18-821	3-H6	BV11-19-384	1-J9	BV11-19-580A	1-M10	BV65-19-613	1-H11
R502-17-306A	1-L7	R501-17-555	1-H7	NF01-18-X65	1-L8	NF02-18-821A	3-L6	BV11-19-314	1-K9	BV11-19-581	1-M10	BV66-19-613	1-H11
0727-17-306	1-L7	R526-17-570	1-H7	NS26-18-X65	1-L8	NSA1-18-831	3-L6	BV11-19-303	1-F11	BV65-19-5D0	1-M10	BV65-19-615	1-H11
R524-17-308	1-L7	P501-17-575	1-I7	F214-18-X66	1-N8	NSA2-18-831A	3-L6	BV11-19-304	1-F11	BV65-19-5D0A	1-M10	BV65-19-615	1-H11
M501-17-309	1-L7	R523-17-610	1-M7	F214-18-X70	1-N8	NSA1-18-835	3-L6	BV55-19-304	1-F11	BV11-19-5D1A	1-M10	BV11-19-616	1-H11
R505-17-310B	1-M7	R501-17-612	1-M7	JF01-18-X70	1-N8	F202-18-840A	3-L6	BV11-19-305	1-L10	BV11-19-5D1B	1-M10	BV45-19-616	1-H11
0821-17-313	1-M7	R501-17-613	1-M7	NF01-18-X70	1-N8	NF02-18-840	3-L6	BV11-19-306	1-F11	BV11-19-5D2	1-M10	BV65-19-616	1-H11
0884-17-315	1-M7	R504-17-620	1-M7	NS18-18-X71	1-N8	NS370-18-840	3-J6	BV11-19-307	1-F11	BV11-19-5D3	1-N10	BV65-19-617	1-H11
R502-17-316	1-M7	R502-17-621A	1-N7	NS26-18-X71	1-N8	NS91-18-840	1-K4	BV65-19-310	1-J9	BV11-19-5D4	1-N10	BV11-19-618	1-H11
4069-17-323	1-M7	3648-17-629	1-N7	NF01-18-X75	1-L8	NSA1-18-845	3-J6	BV11-19-311	1-L10	BV11-19-5F1	1-I11	BV11-19-620	1-C11
0884-17-325B	1-F7	R501-17-631A	1-N7	NS18-18-X80A	1-M8	NSA1-18-861A	3-J6	BV11-19-322	1-G11	BV11-19-5H0	1-N10	BV11-19-620A	1-C11
0305-17-327	1-M7	R501-17-632A	1-N7	NS26-18-X87	1-N8	ESA1-18-867	3-J6	BV11-19-324	1-G11	BV11-19-5J0	1-N10	BV11-19-622	1-H11
0305-17-328	1-M7	R501-17-633A	1-N7	NF01-18-X90	1-M8	NSA1-18-881	3-J6	BV11-19-331	1-J9	BV11-19-5J1	1-N10	0338-19-622	1-F11
R526-17-330	1-F7	R501-17-634A	1-N7	NS26-18-X91	1-M8	NSA1-18-881A	3-J6	0338-19-331A	1-J9	BV11-19-5J3	1-N10	BV65-19-623	1-H11
R526-17-330A	1-F7	R501-17-635	1-N7	NF01-18-X92	1-L8	NSA2-18-881	3-J6	BV11-19-336	1-G11	BV11-19-5J4	1-N10	BV65-19-625	1-H11
G540-17-335	1-F7	R501-17-636	1-N7	NS26-18-X92	1-M8	NSA2-18-881A	3-J6	BV55-19-336	1-G11	BV11-19-5K2	1-N10	BV65-19-626	1-H11
R501-17-335A	1-F7	R506-17-640	3-H6	NS26-18-X93	1-M8	NSA2-18-881B	3-J6	BV11-19-337	1-G11	BV65-19-5K2	1-N10	BV65-19-627	1-H11
R401-17-337A	1-D7	R507-17-640	3-H6	E356-18-X95	1-L8	NSA3-18-881	3-J6	BV11-19-338	1-G11	BV11-19-5K3	1-N10	BV65-19-628	1-H11
R504-17-337	1-F7	R508-17-640	3-H6	NF01-18-X95	1-L8	NSA3-18-881A	3-J6	BV11-19-341	1-J11	BV65-19-5K3	1-N10	BV45-19-651	1-C11
R505-17-337	1-F7	0821-17-641B	1-N7	NSA1-18-09XA	3-F8	NSA4-18-881	3-J6	BV11-19-347	1-J9	BV11-19-5K4	1-N10	BV11-19-655	1-I11
R502-17-338	1-F7	M502-17-651	1-N7	NSA2-18-09XA	3-F8	NSA4-18-881A	3-J6	BV65-19-360	1-L10	BV65-19-5K4	1-N10	BV11-19-669	1-D10
BV41-17-341	1-G11	M502-17-652	1-N7	NSA2-18-09XA	3-F8	NSA4-18-881B	3-J6	BV11-19-361	1-K9	BV11-19-5K5	1-N10	BV45-19-669	1-D10
R502-17-341A	1-M7	M502-17-653	1-N7	NSA1-18-09Y	3-F8	NSA2-18-882	3-J6	BV11-19-363	1-K9	BV65-19-5K5	1-N10	BV45-19-670	1-I11
M501-17-342	1-M7	M502-17-654	1-N7	NSA1-18-05ZC	3-F8	NSA2-18-883	3-J6	BV65-19-363	1-K9	BV11-19-5K6	1-N10	BV56-19-688	1-L9
R501-17-351	1-D8	M502-17-655	1-N7	NSA1-18-05ZD	3-F8	NSA1-18-890	2-D6	BV11-19-379	1-L10	BV65-19-5K6	1-N10	BV11-19-7A1	1-D10
0114-17-351	1-D8	0462-17-660C	1-I7	NSA1-18-05ZE	3-F8	NSA2-18-9E1	3-J6	BV11-19-381	1-K9	BV11-19-5K7	1-N10	BV11-19-7A3	1-L9
R502-17-371	1-G7	W501-17-724	1-N7	NSA2-18-05ZD	3-F8	NSA2-18-9E1A	3-J6	BV11-19-384	1-K9	BV11-19-5K8	1-C11	BV11-19-701	1-F9
R501-17-372	1-G7	W501-17-725A	1-N7	NSA2-18-05ZE	3-F8	NSA2-18-9E1B	3-J6	BV11-19-385	1-K9	BV11-19-5K9	1-C11	BV11-19-704	1-F9
R501-17-373	1-G7	W501-17-725B	1-N7	NSA2-18-05ZF	3-F8	NSA1-18-911	1-D5	BV11-19-386	1-K9	BV45-19-500	1-C11	BV11-19-707	1-J11
0810-17-381A	1-G7	R501-17-732	1-C8	NSA2-18-05ZG	3-F8	NSA2-18-911	1-D5	BV11-19-387	1-J11	BV11-19-503	1-C11	BV65-19-710	1-L9
R501-17-385A	1-G7			NSA3-18-05Z	3-F8	NSA1-18-921	3-J6	BV11-19-388	1-K9	BV11-19-504	1-C11	BV11-19-726	1-F9
BV65-17-400	1-J9			NSA2-18-05A	3-F8			BV11-19-389	1-K9	BV11-19-505	1-C11	BV11-19-732	1-J11
R505-17-400A	1-G7			NSA1-18-100	1-F8			BV11-19-391	1-K9	BV11-19-506	1-C11	BV11-19-733	1-J11
R505-17-400B	1-G7			NSA2-18-100	1-F8			0338-19-395	1-K9	BV11-19-507	1-C11	BV11-19-734	1-K11
R522-17-402	1-D8			NSA3-18-100	1-F8			BV11-19-397	1-L9	BV11-19-508	1-C11	BV35-19-735	1-M9
R501-17-404B	1-D8			NSA2-18-105A	1-F8			0338-19-397	1-L9	BV45-19-510	1-D11	BV60-19-735	1-M9
R505-17-406	1-E8			NSA1-18-110	1-G8			BV11-19-481	1-L10	BV11-19-520	1-D11	BV12-19-737	1-M9
R522-17-411	1-E8			NSA2-18-110	1-F8			BV11-19-482	1-L10	BV11-19-521	1-D11	BV40-19-737	1-M9
0103-17-411	1-E8			NSA3-18-110	1-F8			BV11-19-483	1-L10	BV11-19-522	1-D11	0338-19-739	1-M9
R502-17-412A	1-D8			NSA4-18-110	1-F8			BV11-19-484	1-G11	BV11-19-523	1-D11	BV65-19-750	1-D10
R505													

PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

FD01-67-060E	J-D8	FD04-67-501A	J-L8	FD01-68-J30 02	J-M9	FD01-68-450033	J-M3	FD01-68-710A02	J-L9	N3A1-69-036	J-L10	FD01-69-851	J-C6
FD04-67-060C	J-D8	FD05-67-501	J-L8	FD01-68-J30A02	J-M9	FD01-68-450033	J-M3	FD01-68-710A17	J-L9	N3A2-69-036	J-L10	FD01-69-852	J-C6
FD04-67-060D	J-D8	FD01-67-502	J-L8	FD01-68-J40 02	J-M9	FD01-68-450017	J-M3	FD01-68-710A33	J-L9	N3A3-69-036	J-L10	FD01-69-858	J-D6
FD01-67-070E	J-G8	4116-67-502	J-E9	FD01-68-J40A02	J-M9	FD01-68-450F33	J-M3	B456-68-712	J-L9	N3A4-69-036	J-L10	FD01-69-859	J-D6
FD01-67-070G	J-G8	D061-67-505	J-L8	FD01-68-J5Y 02	J-N9	FD05-68-9CX 02	J-C11	FD01-68-720A02	J-L9	N3A1-69-044A	J-L10	FD01-69-861	J-D6
FD01-67-070H	J-G8	LA01-67-505B	J-E9	FD09-68-J5Y 02	J-N9	FD05-68-9CX 17	J-C11	FD01-68-720A17	J-L9	FA01-69-064A	J-L10	FD01-69-864	J-C6
FD01-67-070J	J-G8		J-L8	M001-68-0C0A	J-H9	FD05-68-9CX 33	J-C11	FD01-68-720A33	J-L9	HG30-69-065	J-L10	FD01-69-865	J-D6
FD02-67-070	J-G8	FD01-67-508	J-L8	FD01-68-021	J-H9	FD05-68-9C1 02	J-M10	B216-68-755	J-J3	NA01-49-068A	J-L10	EA05-69-871	J-D6
FD02-67-070A	J-G8	FD01-67-509	J-L8	FD01-68-030B02	J-H9	FD05-68-9C1 17	J-M10	FD01-68-8h2	J-M9	FD03-69-074	J-K10	EA05-69-872	J-D6
F100-67-071E	J-E8	FD02-67-509	J-L8	FD01-68-030B17	J-H9	FD05-68-9C1 33	J-M10	FD01-68-8h7	J-M9	HG30-69-119	J-N5	EA05-69-873	J-C6
F801-67-095	J-E8	FD01-67-510 J9	J-M8	FD01-68-030B33	J-H9	FD01-68-9H0 02	J-M10	FD01-68-8T0A02	J-L9	FD01-69-123	J-L10	FD03-69-896A	J-E6
H115-67-099	J-F8	FD01-67-510 NU	J-M8	FD01-68-030C02	J-H9	FD01-68-9H0 17	J-M10	FD01-68-8T0B02	J-L9	FD01-69-133	J-L10	FD03-69-897	J-E6
H116-67-099	J-F8	FD01-67-510 O3	J-M8	FD01-68-030C17	J-H9	FD01-68-9H0 33	J-M10	FD01-68-8V0A02	J-M9	HG31-69-220 02	J-L10	GA28-69-897	J-E6
J001-67-099	J-G8	FD02-67-510 J9	J-L8	FD01-68-030C33	J-H9	FD05-68-9NX 02	J-C11	FD01-68-8V0B02	J-M9	HG31-69-220A02	J-L10	GA28-69-897	J-E6
FD01-67-100C	J-E8	FD02-67-510 NU	J-L8	FD03-68-030B02	J-H9	FD05-68-9NX 33	J-C11	FD01-68-8V0C02	J-M9	FD01-69-240 J9	J-H10	FD01-69-9H1	J-E6
FD04-67-100C	J-E8	FD02-67-510 O3	J-L8	FD03-68-030B17	J-H9	FD05-68-9NX 17	J-C11	FD01-68-8W0A02	J-M9	FD01-69-240 M8	J-H10	FD01-69-9H2	J-E6
FD04-67-100D	J-E8	FD03-67-510	J-E9	FD03-68-030B33	J-H9	FD05-68-9NX 33	J-C11	FD01-68-8W0B02	J-M9	FD01-69-240 NU	J-H10	FD01-69-9H3	J-E6
FD04-67-100E	J-E8	B499-67-519	J-F9	FD03-68-030C02	J-H9	FD05-68-9N1 02	J-N10	FD01-68-82X 02	J-F10	FD01-69-240 PZ	J-H10	FD01-69-9H4	J-E6
FD01-67-180D	J-J8	FD01-67-560	J-C7	FD03-68-030C17	J-H9	FD05-68-9N1 17	J-N10	FD01-68-82X 17	J-F10	FD01-69-240 ZL	J-H10	FD04-69-920	J-E6
FD01-67-190C	J-J8	FD01-67-560A	J-C7	FD03-68-030C33	J-H9	FD01-68-9W0 02	J-M10	FD01-68-82X 32	J-F10			FD01-69-921	J-E6
FD01-67-190D	J-J8												
FD01-67-190E	J-J8	FD01-67-580	J-C7	0003-68-032	J-J15	FD01-68-9W0 17	J-M10	FD01-68-83X	J-F10	HG31-69-240	J-N5	FD04-69-922	J-F6
FD04-67-190C	J-J8	FD02-67-580	J-C7	GM09-68-049 02	J-H9	FD01-68-9W0 33	J-M10	FD05-68-83XA	J-F10	FD01-69-242 J9	J-H10	FD01-69-923	J-E6
FD04-67-190D	J-J8	M020-67-6D1	J-C7	GM09-68-049 17	J-H9	FD01-68-905	J-M10	FD01-68-850C02	J-M9	FD01-69-242 M8	J-H10	EA05-69-924	J-D6
FD01-67-200C	J-J8	FD01-67-650	J-C7	GM09-68-049 33	J-H9	FD01-68-909	J-M10	FD01-68-850D02	J-M9	FD01-69-242 NU	J-H10	F100-69-926	J-E6
FD01-67-200D	J-J8	FD01-67-7F0B	J-C7	NA01-68-070	J-G10	FD01-68-91X0	J-N3	FD01-68-857 02	J-M9	FD01-69-242 PZ	J-H10	F100-69-926A	J-F6
FD04-67-200C	J-J8	FD01-67-7F0C	J-C7	FD01-68-151 02	J-D10	FD01-68-91YD	J-N3	BF70-68-865 00	J-F10	FD01-69-242 3L	J-H10	KA02-69-926	J-E6
FD04-67-200E	J-J8	KA32-67-720	J-C7	FD01-68-160E02	J-J9	FD01-68-920D02	J-N10	BF70-68-865 33	J-F10	GASR-69-261 02	J-J10	GA28-69-927	J-F6
FD01-67-240E	J-E8	GE10-67-730	J-C7	FD01-68-165	J-J9	FD01-68-920D17	J-N10	BR70-68-865	J-D4	GASR-69-261 17	J-J10	FD01-69-929	J-E6
F100-67-270A	J-E8	KE10-67-730	J-C7	FD01-68-170E02	J-J9	FD01-68-920D33	J-N10	B040-68-865A00	J-D4	GASR-69-263 02	J-J10	FD01-69-960 02	J-D6
GJ21-67-306	J-N8	H022-67-740	J-D7	GD30-68-213B	J-D10	FD01-68-920E17	J-N10	B040-68-865A18	J-D4	GASR-69-263 17	J-J10	FD01-69-960 17	J-D6
FD01-67-321	J-N8	H270-67-740	J-C7	B100-68-215A	J-K9	FD01-68-920E33	J-N10	B102-68-865A33	J-D4	GASR-69-263 33	J-J10	FD01-69-960A02	J-D6
FD02-67-321	J-N8					FD05-68-920E02	J-N10			FD01-69-270C02	J-H10	FD01-69-960A17	J-D6
FD01-67-330	J-N8					FD05-68-920D17	J-N10			FD01-69-270C17	J-H10	FD01-69-960A33	J-D6
FD01-67-330A	J-N8	H302-67-740	J-D7	0208-68-230	J-G10	FD05-68-920D33	J-N10	B103-68-865	J-D4	FD01-69-270C33	J-H10	FD01-69-970C02	J-D12
FD03-67-330	J-E9	LA10-67-740	J-D7	B101-68-252 00	J-D10	FD05-68-920D02	J-N10	B455-68-865 00	J-F10	FD03-69-270C02	J-H10	FD01-69-970C17	J-D12
GAD7-67-330	J-N8	F100-67-741	J-D7	B101-68-252 33	J-D10	FD05-68-920E02	J-N10	GJ12-68-865	J-C11	FD03-69-270C17	J-H10	FD01-69-970C33	J-D12
HG31-67-330	J-N8	FC33-67-830	J-D7	FD01-68-301 02	J-L5	FD05-68-920E17	J-N10			FD03-69-270C33	J-H10	FD03-69-970C02	J-D12
B461-67-331	J-E9	FD01-67-980	J-D7	FD01-68-305	J-N12	FD05-68-920E33	J-N10			FD01-69-276	J-C11	FD03-69-970C17	J-D12
FD01-67-331	J-N8	FD01-67-980A	J-D7	FD05-68-310C02	J-K9	FD01-68-950D02	J-N10			FD01-69-276A	J-C11	FD03-69-970C33	J-D12
F100-67-331	J-N8	FD01-67-981A	J-D7	EA01-68-315	J-K9	FD01-68-950D17	J-N10						
H381-67-331	J-N8	FD01-67-9C1	J-D7	FD01-68-351	J-K9	FD01-68-950E02	J-N10	GJ21-68-865	J-I9	GASR-69-277 02	J-J10	EA01-69-973	J-D12
LA02-67-331A	J-N8			FD01-68-352	J-K9	FD01-68-950E17	J-N10			GASR-69-277 17	J-J10	EA05-69-973	J-D12
FD01-67-340	J-N8	*****		FD01-68-353	J-L9	FD01-68-950E33	J-N10	G032-68-865A00	J-F10	GASR-69-277 33	J-J10	FD02-69-973	J-D12
FD02-67-340	J-N8	* 68-000 *		FD03-68-356	J-K9	FD05-68-950D02	J-N10	FD01-68-870C02	J-M9	FD01-69-320C02	J-H10	FD05-69-973	J-D12
FD01-67-351	J-O9	* 68-000 *		FD01-68-357	J-L9	FD05-68-950D17	J-N10	FD01-68-870D02	J-M9	FD01-69-320C17	J-H10	FD01-69-98X	J-I9
FD02-67-351	J-O9	*****		FD01-68-371A02	J-L9	FD05-68-950E17	J-N10	FD01-68-870E02	J-M9	FD01-69-320C33	J-J10	FD01-69-981 02	J-C6
F063-67-354	J-O9			FD01-68-371A17	J-L9	FD05-68-950E33	J-N10	FD01-68-877 02	J-N9	FD03-69-320C02	J-J10	FD01-69-981 17	J-C6
FD01-67-360	J-N8	LA10-68-AA1	J-I10	FD01-68-371A33	J-L9	FD05-68-950E02	J-N10	GJ21-68-885B00	J-M9	FD03-69-320C17	J-J10	FD01-69-981 33	J-C6
FD02-67-360	J-N8	LA10-68-AA2	J-I10	FD01-68-391A02	J-L9	FD05-68-950E17	J-N10			FD03-69-320C33	J-J10	FD01-69-981A02	J-C6
FD01-67-361	J-C9	FD01-68-AB1A	J-K9	FD01-68-391A17	J-L9	FD05-68-950E33	J-N10			B316-69-361	J-N3	FD01-69-981A17	J-C6
FD01-67-362	J-C9	FD01-68-AB1B	J-K9	FD01-68-391A33	J-L9	FD01-68-6A1	J-E10	GJ21-68-885B02	J-M9	FD01-69-44XA00	J-L3	FD01-69-981A33	J-C6
FD01-67-363	J-N8	G350-68-AB1	J-K3	FD01-68-4H0 02	J-K3	FD01-68-6A2	J-E10			FD01-69-44XB00	J-L3		
FD02-67-363	J-N8	8467-68-AC3	J-O2	FD01-68-4H0 17	J-K3	FD01-68-6F6A02	J-D10	GJ21-68-885B17	J-I9	FD01-69-67Y	J-G10		
FD01-67-364	J-C9			FD01-68-4H0 33	J-K3	FD01-68-6F6A33	J-D10			FD01-69-67YA	J-G10		
FD02-67-364	J-C9			FD01-68-4Y 00	J-K3	FD01-68-6L1A	J-D10	GJ21-68-885B33	J-I9	FD01-69-760B02	J-C10		
FD01-67-366	J-E9			FD01-68-4M0A00	J-L3	FD01-68-6L2A	J-D10			FD01-69-760B17	J-C10		
LA01-67-395A	J-N8	B467-68-AC3	J-17	FD01-68-4M0B00	J-L3	FD01-68-6L3A	J-D10	G030-68-885C00	J-I12	FD01-69-760B33	J-C10		
FD01-67-402	J-O9	8467-68-AC3	J-33	FD01-68-4M0C00	J-L3	FD01-68-6N6	J-E10	UB54-68-885 02	J-F10	FD01-69-760C02	J-C10		
FD01-67-407	J-F9	FD01-68-AC3	J-G10	FD01-68-4W0 02	J-L3	FD01-68-6N7	J-E10	UB54-68-885 82	J-F10	FD01-69-760C17	J-C10		
FD01-67-421	J-E9	8499-68-AD1A	J-L5	FD01-68-4W0 17	J-L3	FD01-68-6O18	J-I12	FD01-68-89X 02	J-N9	FD01-69-760C33	J-C10		
				FD01-68-4W0 33	J-L3								
FD01-67-450A	J-E9	B455-68-AD2	J-L5	H380-68-402	J-L3	B100-68-615	J-2F7	FD01-68-911A02	J-F3	FD01-69-768 02	J-C10	FD01-70-020B	J-D13
FD01-67-451	J-G9	H380-68-AD3	J-K9	FD01-68-406 02	J-L3			FD01-68-912A02	J-G3	FD01-69-768 17	J-C10	FD01-70-030D	J-E13
FD01-67-480B	J-L8	FD01-68-AD4A	J-K9	FD01-68-406 17	J-L3			FD01-68-930A02	J-M5	FD01-69-768 33	J-C10	FD01-70-050	J-D13
FD02-67-480	J-E9	FD01-68-AD4B	J-K9	FD01-68-406 33	J-L3			FD01-68-940B02	J-M5	FD01-69-768A02	J-C10	FD01-70-1X1	J-E13
FD01-67-481A	J-M8	FD01-68-DDXC00	J-K3	FD01-68-411	J-L3			FD01-68-950B02	J-M5	FD01-69-768A17	J-C10	FD01-70-11Y	J-D13
FD02-67-481	J-F9	FD01-68-DDXD00	J-K3	FD01-68-412A	J-L3	FD01-68-63XD	J-D10	FD01-68-960B02	J-M5	FD01-69-768A33	J-C10	FD01-70-11ZA	J-D13
FD01-67-482	J-M8	FD01-68-DDYC00	J-K3	FD01-68-413A	J-M3	FD01-68-63XE	J-E10	FD01-68-960C02	J-M5	FD01-69-771A02	J-C10	FD01-70-11ZC	J-D13
FD02-67-482	J-F9	FD01-68-DDYD00	J-K3	FD01-68-414A	J-M3	FD05-68-63XD	J-D10			FD01-69-771A17	J-C10	FDY1-70-110A	J-D13
FD01-67-483	J-M8	FD01-68-DJXB	J-M3	FD01-68-420E02	J-M3	FD05-68-63XE	J-E10			FD01-69-771A33	J-C10	FD01-70-119	J-N13
FD02-67-483	J-F9	FD01-68-DJXC	J-M3	FD01-68-420E17	J-M3	FD01-68-644A	J-D10			FD01-69-781 02	J-C10	FD01-70-12XA	J-D13
FD02-67-484	J-F9	FD01-68-DJYB	J-N3	FD01-68-420E33	J-M3	FD01-68-648	J-E10			FD01-69-781 17	J-C10	FD01-70-120B	J-D13
FD01-67-492	J-F9	FD01-68-DJYC	J-N3	FD01-68-420F02	J-M3	FD05-68-648	J-E10			FD01-69-781 33	J-C10	FD01-70-130A	J-E13
FD01-67-5A0B	J-N15	FD01-68-D21	J-J9	FD01-68-420F17	J-M3	FD01-68-649A	J-D10			FD01-69-810A	J-C6	FD01-70-15XB	J-F13
FD01-67-5A0C	J-N15												

PART NUMBER INDEX / INDEX DES NUMEROS DE PIECES / TEILENUMMER-INDEX / INDICE DE NUMERO DE PARTES

FD01-70-242B	N-D13	FD01-76-202	N-D10	FD05-88-161	02 2-J16	99655-90030	2-H5
FD01-70-252A	N-E13	FD01-76-210	N-C10	FD05-88-161	17 2-J16	99655-90035	2-H5
FD01-70-272B	N-E13	FD01-76-250	02 2-C10	FD05-88-161	33 2-J16	99655-90040	2-H5
FD01-70-274A	N-E13	FD01-76-260	N-C10	FD01-88-162	2-N16	99655-90045	2-H5
FD01-70-311A	N-E13	FD01-76-290	N-C10	FD01-88-174	2-N16	99655-90050	2-I5
FDY1-70-400B	N-H13	FD02-76-290	N-C10	FD01-88-180	02 2-J16	99655-90055	2-I5
FD01-70-440B	N-E13	8093-76-605	N-E9	FD03-88-180	02 2-K16	99655-90060	2-I5
FD01-70-490B	N-E13	8002-76-619A	N-G9	FD05-88-180	02 2-K16	99700-5080	2-N12
0187-70-491	N-D7	8043-76-619A	N-D9	FD05-88-180	17 2-K16	99700-7180	2-N11
FD04-70-600B	N-I13	8093-76-641	N-F9	FD05-88-180	33 2-K16	99701-3270	2-N11
FD01-70-601A	N-I13	8094-76-662	N-D9	FD01-88-181	02 2-K16	99701-4278	2-N11
FD01-70-610A	N-C13	8094-76-663	N-D9	FD03-88-181	02 2-K16	99701-6030	2-E15
FD01-70-640	N-I13	8084-76-677	N-M8	FD05-88-181	02 2-K16		2-G15
	N-I13	HA14-76-707	N-J5	FD05-88-181	17 2-K16	99701-6040	2-N11
FD01-70-651A	N-D13	HD01-76-714	N-J5	FD05-88-181	33 2-K16	99701-6049	2-N11
FD01-70-661	N-I13	HD01-76-717	N-J5	FD01-88-6D0	02 2-K16	99701-6050	2-D12
FD01-70-700B	N-I13	8001-76-725	N-E5	FD03-88-6D0	02 2-K16		2-N11
	N-I13		N-O5	FD05-88-6D0	02 2-K16		2-N11
FD01-70-750C	N-F13	8001-76-734	N-E5	FD05-88-6D0	17 2-K16	99703-4350	2-E11
	N-F13		N-O5	FD05-88-6D0	33 2-K16	99703-8605	2-M10
*****		*****		FD01-88-6D2	02 2-K16	99705-1115	3-C8
* 71-000 *		* 88-000 *		FD03-88-6D2	02 2-L16		3-H8
*****		*****		FD05-88-6D2	02 2-L16	99705-1130	3-C8
				FD05-88-6D2	17 2-L16		3-H8
FD01-71-020B	N-F13	FD01-88-005	N-H16	FD05-88-6D2	33 2-L16	99963-6930	1-J7
FD01-71-030C	N-G13	FD01-88-004	N-H16	8456-88-815	2-L16	99963-6940	1-J7
FD01-71-030D	N-G13	FD01-88-062	N-G16	B260-88-818	2-L16	99963-6950	1-J7
FD01-71-050	N-F13	FD01-88-072	N-G16	EA01-88-818	2-L16	99963-6960	1-J7
FD01-71-180A	N-F13	FD01-88-073	N-G16	*****		99963-6970	1-J7
FD01-71-100	N-F13	FD01-88-101	02 2-G16	* 90-000 *			
FD01-71-1X1	N-G13	FD01-88-101	17 2-G16	*****			
FD01-71-11Y	N-F13	FD01-88-101	43 2-G16	90620-17636	2-H5		
FD01-71-11Z	N-F13	FD01-88-105	02 2-G16	90620-55726	2-H5		
FD01-71-11ZB	N-F13	FD01-88-105	17 2-G16	90620-75726	2-H5		
FDY1-71-11ZC	N-F13	FD01-88-1H3	02 2-G16	90621-65726	2-H5		
FD01-71-110A	N-F13	FD01-88-1H3	17 2-G16	90621-85726	2-H5		
FD01-71-119	N-F13	FD01-88-1H3	33 2-H16				
FD01-71-120B	N-F13	FD01-88-1H5	02 2-G16	90622-65726	2-H5		
		FD01-88-1H5	17 2-G16	90701-7270	2-E11		
FD01-71-131A	N-E13	FD01-88-1H5	33 2-G16	*****			
FD01-71-15XB	N-H13	FD01-88-101	N-H16	* 99-000 *			
FD01-71-15XC	N-H13	FD01-88-102	N-H16	*****			
FD01-71-15XD	N-H13	FD01-88-103	N-H16	99236-0571	1-J3		
FD01-71-150C	N-G13	FD01-88-106	N-H16	99324-07200	1-L6		
FD01-71-150E	N-G13	FD01-88-106	N-H16	99324-07400	1-L6		
FDY1-71-200	N-G13	H115-88-108	N-H16	99328-04010	3-F9		
FD01-71-230A	N-G13	FD01-88-110	02 2-H16	99340-05540	1-H9		
FDY1-71-24X	N-G13	FD05-88-110	02 2-H16	99351-04999	1-E6		
FDY4-71-24X	N-G13	FD05-88-110	17 2-H16				
FD01-71-242B	N-D13	FD05-88-110	33 2-H16	99351-06999	2-C7		
FD01-71-252A	N-G13	FD01-88-111	02 2-H16	99351-08999	1-I4		
FD01-71-272B	N-G13	FD03-88-111	02 2-I16	99359-0814	1-I4		
FD01-71-274A	N-G13	FD05-88-111	02 2-I16	99359-0815	2-F8		
FD01-71-311A	N-G13	FD05-88-111	17 2-I16				
FDY1-71-400B	N-H13	FD05-88-111	33 2-I16	99359-0815M	2-H8		
FD01-71-440B	N-G13	FD01-88-124	2-F16	99359-0819	2-F8		
FD01-71-490B	N-G13			99541-00603	2-I7		
FD01-71-651A	N-F13	FD01-88-130	02 2-I16	99541-01105	1-K3		
*****		FD03-88-130	02 2-I16	99541-01201	1-J9		
* 76-000 *		FD05-88-130	17 2-I16	99541-01252	1-J4		
*****		FD05-88-130	33 2-I16	99541-01401	2-K4		
0208-76-071	3-F9	FD01-88-131	02 2-I16	99541-01601	1-D6		
	3-F10	FD03-88-131	02 2-I16				
FD01-76-120 J9	3-H10	FD05-88-131	17 2-I16	99606-23030	1-M6		
FD01-76-120 M8	3-H10	FD05-88-131	33 2-I16	99611-2500	1-O8		
FD01-76-120 NU	3-H10	FD01-88-152	2-J16	99636-04130	2-H5		
FD01-76-120 PZ	3-H10	FD01-88-153	2-J16	99650-28060	2-I5		
FD01-76-120 3L	3-H10	FD01-88-155	2-I16	99650-58060	2-I5		
FD01-76-180 J9	3-H10	FD01-88-160	02 2-J16	99651-94060	2-I5		
FD01-76-180 M8	3-H10	FD03-88-160	02 2-J16	99655-90005	2-H5		
FD01-76-180 NU	3-H10	FD05-88-160	02 2-J16	99655-90010	2-H5		
FD01-76-180 PZ	3-H10	FD05-88-160	17 2-J16	99655-90015	2-H5		
FD01-76-180 3L	3-H10	FD05-88-160	33 2-J16	99655-90020	2-H5		
FD01-76-190	2-D10	FD01-88-161	02 2-J16	99655-90025	2-H5		
FD01-76-201	2-D10	FD03-88-161	02 2-J16				

ALPHABETICAL INDEX MM ENGLISH MM

CAP, TANK-----3-M8
 CAP, VANE PUMP TANK-----2-K4
 CAP, WATER INLET-THERMO C.-----1-K6
 CARRIER, DIFFERENTIAL-----2-K3
 CARRIER, FRONT-----1-D11
 CARRIER, REAR-----1-E11
 CARTRIDGE OIL FILTER-----1-D6
 CASE(L), BLOWER-----1-H4
 CASE(L), HEATER UNIT-----1-E4
 CASE(R), BLOWER-----1-H4
 CASE(R), HEATER UNIT-----1-E4
 CASE, CHANGE CONTROL-----1-E8
 CASE, HEATER-----1-E4
 CASE, LAMP-----1-C15
 CASE, METER-----1-F9
 CASE, RELAY BOX-----1-F7
 CASE, T/MISSION-----1-F9
 CASE, WARNING UNIT-----1-E15
 CASE 'A', COOLING UNIT-----1-H5
 CASE 'B', COOLING UNIT-----1-H5
 CASE 'C', COOLING UNIT-----1-I5
 CASE 'C', HEATER UNIT-----1-E4
 CATALYST, TREE WAY-----2-D6
 CEILING, TOP-----1-H9
 CHAIN, OIL PUMP-----1-C6
 CHAMBER, EXTRACTOR-----2-G12
 CHAMBER, VACUUM-----1-K5
 CHANGE COMPLETE-----1-I8
 CHANNEL(L), GLASS-----1-E3
 CHANNEL(R), GLASS-----1-E3
 CHARGE, AIR COOLER-----1-D4
 CHECKER, DOOR-----1-H3
 CLAMP-----1-K4
 CLAMP, BATTERY-----1-C9
 CLAMP, HOSE-----1-E5
 CLAMP, SPARE TIRE-----1-I5
 CLAMP, WATER HOSE-----1-J6
 CLIP-----1-F7
 CLIP, AIR BAG-----2-M7
 CLIP, BELTLINE MOULD-----3-C3
 CLIP, C.S.D. WIRE-----2-E7
 CLIP, COOLING UNIT-----3-15
 CLIP, DRAIN HOSE-REAR-----3-E6
 CLIP, DRAIN HOSE-SUN ROOF-----3-E6
 CLIP, FENDER GRILLE-----2-G12
 CLIP, FLEXIBLE HOSE-----2-J6
 CLIP, HARNESS-----1-E10
 CLIP, HEATER UNIT-----1-F10
 CLIP, HOSE-----3-K8
 CLIP, HOSE-SUB T. & WATER H-----1-L6
 CLIP, M. OIL TUBE-----1-H6
 CLIP, MUD GUARD-----2-M12
 CLIP, OIL TUBE-----1-H6
 CLIP, PARKING CABLE-----2-E6
 CLIP, PIPE-----2-O8
 CLIP, PROTECTOR-----2-L7
 CLIP, RR BRAKE PIPE-----2-H12
 CLIP, RR WINDOW MOULD-----2-J10
 CLIP, SCUFF PLATE-----3-K9
 CLIP, SLIDE-----3-L5
 CLIP, SPOILER-----3-E11
 CLIP, STEP MOULD-----2-F12
 CLIP, TOP CEILING-----3-H9
 CLIP, TRIM-----3-C11
 CLIP, WASHER HOSE-----3-E9
 CLIP, WIRE-BONNET-----1-F9
 CLIP 'A', BELTLINE MOULD-----2-K10
 CLUTCH-----2-D3
 CLUTCH & ONE WAY-----2-E8
 CLUTCH, HIGH-----2-E10
 CLUTCH, MAGNET-----2-F8
 CLUTCH, ONE WAY-----2-P12
 CLUTCH, REAR-----2-G11
 CLUTCH, REVERSE-----2-G12
 COCK, DRAIN-----2-G16
 COIL, FIELD-MAGNET CLUTCH-----2-J15
 COIL, IGNITION-LEADING-----2-K4
 COIL, IGNITION-TRAILING-----2-K10
 COLLAR-----2-N10
 COLLAR, CLUTCH REL.-----3-C3
 COLLAR, COMP. BRKT-----3-C6
 COLLAR, WEDGE-----3-D4
 COMPRESSOR-----3-E6
 COMPRESSOR, AIR CON.-----3-H3
 CONDENSER-----3-H10
 CONNECTOR, HOSE-----3-Y3
 CONNECTOR, HOSE-----3-I6
 CONNECTOR, HOSE-----3-J3
 CONNECTOR, HOSE-----3-L4
 CONNECTOR, HOSE-----3-L5
 CONNECTOR, HOSE-----3-K4
 CONNECTOR, OIL COOLER-----3-K5
 CONNECTOR, SHORT-----3-K7
 CONNECTOR, WATER HOSE-----3-L7
 CONSOLE, OVERHEAD-----3-K8
 CONSOLE, REAR-----3-L5
 CONTROL UNIT-----3-L7
 CONTROL UNIT-----3-L8
 CONTROL UNIT-----3-L9
 CONTROL UNIT-----3-M4
 CONTROL UNIT-----3-N4
 CONTROL UNIT-----3-N3
 CONTROL UNIT-----3-H3
 CONVERTER, CATALYST-----3-J4
 CONVERTER, TORQUE-----2-D3

CLIP, AIR BAG-----2-M7
 CLIP, BELTLINE MOULD-----3-C3
 CLIP, C.S.D. WIRE-----2-E7
 CLIP, COOLING UNIT-----3-15
 CLIP, DRAIN HOSE-REAR-----3-E6
 CLIP, DRAIN HOSE-SUN ROOF-----3-E6
 CLIP, FENDER GRILLE-----2-G12
 CLIP, FLEXIBLE HOSE-----2-J6
 CLIP, HARNESS-----1-E10
 CLIP, HEATER UNIT-----1-F10
 CLIP, HOSE-----3-K8
 CLIP, HOSE-SUB T. & WATER H-----1-L6
 CLIP, M. OIL TUBE-----1-H6
 CLIP, MUD GUARD-----2-M12
 CLIP, OIL TUBE-----1-H6
 CLIP, PARKING CABLE-----2-E6
 CLIP, PIPE-----2-O8
 CLIP, PROTECTOR-----2-L7
 CLIP, RR BRAKE PIPE-----2-H12
 CLIP, RR WINDOW MOULD-----2-J10
 CLIP, SCUFF PLATE-----3-K9
 CLIP, SLIDE-----3-L5
 CLIP, SPOILER-----3-E11
 CLIP, STEP MOULD-----2-F12
 CLIP, TOP CEILING-----3-H9
 CLIP, TRIM-----3-C11
 CLIP, WASHER HOSE-----3-E9
 CLIP, WIRE-BONNET-----1-F9
 CLIP 'A', BELTLINE MOULD-----2-K10
 CLUTCH-----2-D3
 CLUTCH & ONE WAY-----2-E8
 CLUTCH, HIGH-----2-E10
 CLUTCH, MAGNET-----2-F8
 CLUTCH, ONE WAY-----2-P12
 CLUTCH, REAR-----2-G11
 CLUTCH, REVERSE-----2-G12
 COCK, DRAIN-----2-G16
 COIL, FIELD-MAGNET CLUTCH-----2-J15
 COIL, IGNITION-LEADING-----2-K4
 COIL, IGNITION-TRAILING-----2-K10
 COLLAR-----2-N10
 COLLAR, CLUTCH REL.-----3-C3
 COLLAR, COMP. BRKT-----3-C6
 COLLAR, WEDGE-----3-D4
 COMPRESSOR-----3-E6
 COMPRESSOR, AIR CON.-----3-H3
 CONDENSER-----3-H10
 CONNECTOR, HOSE-----3-Y3
 CONNECTOR, HOSE-----3-I6
 CONNECTOR, HOSE-----3-J3
 CONNECTOR, HOSE-----3-L4
 CONNECTOR, HOSE-----3-L5
 CONNECTOR, HOSE-----3-K4
 CONNECTOR, OIL COOLER-----3-K5
 CONNECTOR, SHORT-----3-K7
 CONNECTOR, WATER HOSE-----3-L7
 CONSOLE, OVERHEAD-----3-K8
 CONSOLE, REAR-----3-L5
 CONTROL UNIT-----3-L7
 CONTROL UNIT-----3-L8
 CONTROL UNIT-----3-L9
 CONTROL UNIT-----3-M4
 CONTROL UNIT-----3-N4
 CONTROL UNIT-----3-N3
 CONTROL UNIT-----3-H3
 CONVERTER, CATALYST-----3-J4
 CONVERTER, TORQUE-----2-D3

COOLER, OIL-----1-F9
 CORD-----1-G9
 CORD-----1-H6
 CORD-----3-E8
 CORD SET, HI. TENSION-----3-K7
 CORD, EARTH-----1-G8
 CORD, EARTH-RADIO-----3-M7
 CORD, HIGH TENSION-----1-G3
 CORD, HIGH TENSION (L-1)-----1-G8
 CORD, HIGH TENSION (L-2)-----1-G8
 CORD, HIGH TENSION (T-1)-----1-G8
 CORD, HIGH TENSION (T-2)-----1-G8
 CORD, LAMP-----2-L11
 CORD, SHORT-----3-D8
 CORE, HEATER-----3-E4
 COVER-----3-C8
 COVER NO. 1, ADJ-FRT-----2-F16
 COVER NO. 1, SIDE-F. SEAT-----2-G16
 COVER NO. 4, SIDE-F. SEAT-----2-G16
 COVER SET-----1-M8
 COVER(L), BUMPER-----2-G10
 COVER(L), DUST-----2-L4
 COVER(L), FOG LAMP-----2-G11
 COVER(L), GLOVE-----2-H15
 COVER(L), QTR. TRIM-----3-C11
 COVER(L), RETRACTOR-----2-N16
 COVER(L), RR COMB.-----2-K11
 COVER(L), SIDE-----2-I15
 COVER(L), TRUNK SIDE-----3-N9
 COVER(R), BUMPER-----2-E10
 COVER(R), DUST-----2-L4
 COVER(R), FOG LAMP-----2-G11
 COVER(R), GLOVE-----2-H15
 COVER(R), QTR. TRIM-----3-C11
 COVER(R), RETRACTOR-----2-N16
 COVER(R), RR COMB.-----2-J11
 COVER(R), SIDE-----2-I15
 COVER(R), SIDE NO. 2-----2-I15
 COVER(R), TRUNK SIDE-----3-N9
 COVER, ACTUATOR-----3-F7
 COVER, AIR CLEANER-----1-N4
 COVER, BEARING-----1-F7
 COVER, BLIND-----1-G7
 COVER, BLIND-EXTENSION HOU-----1-H7
 COVER, BOX-BATTERY-----1-C9
 COVER, CASE-----2-G3
 COVER, CENTER ADAPTER-----3-J10
 COVER, CLUTCH-----1-C7
 COVER, COLUMN-LOWER-----2-C15
 COVER, COLUMN-UPPER-----2-C15
 COVER, DAMPER STAY-----3-K5
 COVER, DUST-----1-C7
 COVER, F. FOG LAMP-----1-G3
 COVER, FRONT-----1-C7
 COVER, FRONT CLUTCH-----1-I8
 COVER, FRONT-ALTERNATOR-----3-H8
 COVER, FUSE BLOCK-----2-F10
 COVER, GRILLE-----2-K15
 COVER, HOLE-----2-M13
 COVER, HOLE (C)-----2-N13
 COVER, HOLE-ANTENNA-----3-H9
 COVER, HOLE-BELT-----3-J3
 COVER, HOLE-DOOR BODY-----3-J3
 COVER, HOLE-LIFT GATE-----3-F9
 COVER, HOLE-RR WIPER-----1-J4
 COVER, INJECTOR-----2-H15
 COVER, LAMP-----2-N11
 COVER, LICENSE LAMP-----3-C8
 COVER, MAIN FUSE BLOCK-----3-F8

COVER, OIL PUMP-----1-E9
 COVER, PEEPING HOLE-----1-C7
 COVER, REAR-----2-K3
 COVER, REAR-ALTERNATOR-----1-18
 COVER, RELAY BOX-F. HARNESS-----3-E8
 COVER, RR FINISHER-----2-L11
 COVER, SERVICE HOLE-----2-N13
 COVER, SOCKET-HEAD LAMP-----2-M10
 COVER, SUN VISOR-----3-J10
 COVER, T/MISSION-----2-C14
 COVER, THERMOSTAT-----1-J6
 COVER, UNDER-----1-D9
 COVER, UNDER-FRONT-----2-C14
 COVER, UNDER-MAIN FUSE BLK-----3-C8
 COVER, UNDER-REAR-----2-C14
 COVER, UNDER-RELAY BOX-----3-C8
 COVER, VENT-----2-G4
 COVER, WHEEL CORE-----2-G4
 COVER, WIPER ARM-FRONT-----3-N8
 COVER, WIPER ARM-REAR-----3-F9
 COVER 'A', FRAME-SLIDE ROOF-----3-D6
 COVER 'A', HOLE-----3-D10
 COVER 'B', FRAME-SLIDE ROOF-----3-D6
 COVER 'B', HOLE-----3-D10
 COVER 'C', HOLE-----3-D10
 COVER 'L', HYDRAULIC UNIT-----2-C8
 COWLING, RADIATOR-----1-K6
 CUP, SECONDARY-----2-I7
 CUSHION(L), FRT SEAT-----2-J16
 CUSHION(R), FRT SEAT-----2-H16
 CUSHION, RUBBER-----3-C10
 CYL., CLUTCH MASTER-----2-H6
 CYL., CLUTCH RELEASE-----2-H6
 CYL., TANDEM MASTER-----2-I7
 DAM, AIR-SKIRT-----3-D11
 DAM, FRT. WGLHD GLASS-----3-N5
 DAMPER(L), FRONT-----2-F5
 DAMPER(L), REAR-----2-C4
 DAMPER(R), FRONT-----2-F5
 DAMPER(R), REAR-----2-C4
 DAMPER, DYNAMIC-----2-F6
 DAMPER, PULSATION-----1-K4
 DASH POT-----1-O5
 DIFFERENTIAL-----2-K3
 DISC, CLUTCH-----1-C7
 DISPLAY, SECURITY-ALARM-----2-N15
 DISTRIBUTOR, FUEL-----1-J4
 DOWEL, TUBULAR-----1-D3
 DRIVING & DIFF.-----2-J3
 DRUM, HIGH CLUTCH-----1-M10
 DRUM, REVERSE-----1-M10
 DUCT NO. 2(L)-----2-H15
 DUCT(L), AIR-BRAKE PIPE-----2-J7
 DUCT(L), LAP-----2-C16
 DUCT(L), SHOWER-----3-C4
 DUCT(L), SIDE DEMIST.-----2-C16
 DUCT(L), VENTILATOR-----2-C16
 DUCT(R), AIR-BRAKE PIPE-----2-J7
 DUCT(R), VENTILATOR-----2-C16
 DUCT, AIR-----3-C4
 DUCT, AIR-INTER COOLER-----1-D4
 DUCT, CENTER-----2-C16
 DUCT, FRESH AIR-----1-L4
 DUCT, OIL COOLER-----1-D9
 DUCT 'A', REAR SPEAKER-----3-J7
 DUCT 'B', RR SPEAKER-----3-J7
 DUCT 'C', RR SPEAKER-----3-J7
 ELEMENT, AIR CLEANER-----1-M4
 END, CONTROL LEVER-----1-G7
 END, S/ROD(1ST&2ND)-----1-D8
 END, S/ROD(3RD&4TH)-----1-D8
 END, SHIFT ROD(C/TOP&REV.)-----1-D8
 ENGINE, SHDRT-----1-C3
 EVAPORATOR-----3-H5
 FACE, FRONT BUMPER-----2-E10
 FAN DRIVE-----1-K6
 FAN(L), COOLING-----1-J6
 FAN(R), COOLING-----1-J6
 FANREL-----3-F9
 FASTENER-----1-D4
 FASTENER-----2-E10
 FASTENER-----2-F12
 FASTENER-----2-I10
 FASTENER-----2-I12
 FASTENER-----2-I12
 FASTENER-----3-F9
 FASTENER-----3-F3
 FASTENER-----3-F10
 FASTENER-----3-G10
 FASTENER-----3-H9
 FASTENER-----3-J9
 FASTENER-----3-K3
 FASTENER-----3-K9
 FASTENER-----3-L5
 FASTENER, BONNET-----3-N4
 FASTENER, CTR. P/UPP.-----2-I12
 FASTENER, DUCT PANEL-----1-H9
 FASTENER, KEY CYL.-----1-L6
 FASTENER, LAMP-----2-C7
 FASTENER, LAMP-----2-M10
 FASTENER, REAR BUMPER-----2-F10
 FASTENER, SEAL-TRIM-----2-I10
 FASTENER, TRIM-SLIDE ROOF-----3-E6
 FASTENER, TRK. S. TRIM-----2-G10
 FEEDER-ANTENNA-----3-K7
 FELT-----3-L7
 FILTER, AIR-----1-J5
 FILTER, AIR-----1-K5
 FILTER, FUEL-----1-I4
 FILTER, FUEL PUMP-----2-L6
 FILTER, GOVERNOR-----1-D10
 FINISHER, REAR-----2-I11
 FLANGE, COMPANION-----2-J3
 FLANGE, REAR AXLE-----2-E3
 FOAM(L), ENGY. ABS.-RR BUMP-----2-H10
 FOAM(R), ENGY. ABS.-RR BUMP-----2-H10
 FORK, BRAKE-----2-E7
 FORK, CLUTCH-----1-L4
 FORK, CLUTCH RELEASE-----1-C7
 FORK, CLUTCH RELEASE-----1-D7
 FORK, SHIFT(1ST&2ND)-----1-D8
 FORK, SHIFT(3RD&4TH)-----1-D8
 FORK, SHIFT-5TH & REVERSE-----1-E8
 FRAME(L), REAR SIDE-----2-K13
 FRAME(L), SIDE-FRONT-----2-L12
 FRAME(L), SIDE-OUTER-----2-G13
 FRAME(R), REAR SIDE-----2-K13
 FRAME(R), SIDE-FRONT-----2-L12
 FRAME(R), SIDE-OUTER-----2-D13
 FRAME, CENTER-REAR SIDE-----2-K13

 * F *

 * D *

 * E *

ALPHABETICAL INDEX *** ENGLISH ***

FRAME, POWER PLANT-----	2-C6	GASKET, SPOILER-----	3-E11	GROMMET, SCREW-----	3-D11	HOLDER, JACK HANDLE-----	1-H9	HOUSING(L), FOG LAMP-----	2-F11
FRAME, SLIDING ROOF-----	3-C6	GASKET, SPRING CAP-----	1-H7		3-E3		2-15	HOUSING(R), BACK UP LAMP-----	2-K11
FRAME, SUB-----	2-F4	GASKET, THERMO-----	1-C5		3-I3	HOLDER, NO. PLATE-----	2-E10	HOUSING(R), FOG LAMP-----	2-F11
FUSE-----	3-H4	GASKET, THERMOSTAT COVER-----	1-J6		3-J3	HOLDER, P. B. VALVE-----	2-C8	HOUSING, AIR CLEANER-----	1-L4
FUSE (120A)-----	3-H8	GASKET, THROTTLE BODY-----	1-T5		3-L3	HOLDER, PIPE-----	2-C7	HOUSING, CLUTCH-----	1-C7
FUSE (15A)-----	3-C8	GASKET, TURBO-----	1-Q4	GROMMET, SCREW-R. COMB-----	3-N3		2-Q8	HOUSING, CONVERTER-----	1-E9
	3-H8	GASKET, TURBOCHARGER-----	1-F4		2-I11		2-L7	HOUSING, EXTENSION-----	1-F7
FUSE (30A)-----	3-C8	GASKET, VAC POWER ASSIST-----	2-H7		3-H3	HOLDER, PIPE-FRT BRAKE(L)-----	2-L7		1-I9
	3-F8	GASKET, VAPOR VALVE-----	2-C7		3-H5	HOLDER, PLATE-----	2-G7	HOUSING, FRONT-----	1-O3
	3-H8	GASKET, WATER DRAIN-INTER-----	1-D3	GROMMET, SCUFF PLATE-----	3-K9	HOLDER, SPINDLE-----	1-H7	HOUSING, GEAR-----	2-4
FUSE (40A)-----	3-F8	GASKET, WATER PUMP-----	1-T6	GROMMET, SIDE GARNISH-----	2-I11	HOLDER, 'B' PIPE-----	2-C8	HOUSING, INTERMEDIATE-----	1-E3
FUSE (60A)-----	3-F8	GASKET, 'A' REINFORCEMENT-----	2-M6	GROMMET, WASH-COOLING-----	3-K4	HOLDER 'C' PIPE-----	2-Q8	HOUSING, REAR-----	1-O3
*****		GASKET 'B' DUST COVER-----	2-M6	GROMMET, WATER TANK-----	3-M8	HOLDER 'E' PIPE-FUEL-----	2-Q8	HOUSING, ROTOR-FRONT-----	1-D3
* * * * *		GAUGE UNIT, OIL PRES-----	3-H6	GUARD(L), MUD-----	2-M12	HOLDER 'F' PIPE-----	2-Q8	HOUSING, ROTOR-REAR-----	1-D3
* * * * *		GAUGE, FUEL TANK-----	2-C7	GUARD(R), MUD-----	2-M12	HOLDER 'G' PIPE-----	2-Q8	HOUSING, WAX-----	1-C5
* * * * *		GAUGE, OIL LEVEL-----	1-E3	GUIDE(L), REAR-----	3-D6	HOLDER 'H' PIPE-----	2-Q8	HUB-----	1-F11
			1-M9	GUIDE(R), REAR-----	3-C6	HOLDER 'K' PIPE-FUEL-----	2-Q8	HUB SET, CLUTCH-O.T. & REV-----	1-M7
GARNISH(L)-----	2-L10	GEAR-----	1-N8	GUIDE, AIR-----	2-E10	HOOD, METER-----	2-D15	HUB SET, CLUTCH-1ST & 2ND-----	1-K7
	3-H10	GEAR SET-----	1-N8	GUIDE, CHANGE-----	1-H7	HOOK(L), TIE DOWN-----	2-L13	HUB SET, CLUTCH-3RD & 4TH-----	1-J7
GARNISH(L), DOOR-----	3-N3	GEAR SET, DRIVEN-SPEED-----	1-G7	GUIDE, PARKING ROD-----	1-J11	HOOK(L), TIE DOWN-FRONT-----	2-M12	HUB(L), SUPPORT-----	2-E3
GARNISH(L), SAIL-INN-----	3-N3		1-J9	GUIDE 'A' (L), GLASS-----	3-E3	HOOK(R), TIE DOWN-----	2-L13	HUB(R), SUPPORT-----	2-E3
GARNISH(R)-----	3-K10	GEAR SET, FINAL-----	2-J3	GUIDE 'A' (R), GLASS-----	3-E3	HOOK(R), TIE DOWN-FRONT-----	2-M12	HUB, CLUTCH-----	1-N7
	3-H10	GEAR, COUNTER-----	1-L7	GUIDE 'B' (L), GLASS-----	3-E3	HORN, HIGH TONE-----	3-E7	HUB, FORWARD CLUTCH-----	1-M2
GARNISH(R), DOOR-----	3-M3	GEAR, COUNTER REVERSE-----	1-L7	GUIDE 'B' (R), GLASS-----	3-E3	HORN, LOW TONE-----	3-E7	HYDRAULIC UNIT, A B S-----	2-N7
GARNISH(R), SAIL-INN-----	3-N3	GEAR, COUNTER SHAFT-----	1-L7	GUSSET(L), RR PILLAR-----	2-F13				
GASKET-----	1-D9	GEAR, DRIVE-----	1-G11	GUSSET(L), SIDE SILL OUTER-----	2-E13				
	1-F7	GEAR, DRIVE-OIL PUMP-----	1-K3	GUSSET(R), SIDE SILL OUTER-----	2-E13				
	1-H6	GEAR, DRIVEN-----	1-D6	*****					
	1-J5	GEAR, INTERNAL-----	1-E11	* * * * *					
	1-J6	GEAR, INTERNAL-STARTER-----	1-L8	* * * * *					
	1-K9	GEAR, MAIN DRIVE-----	1-J7	* * * * *					
	1-L6	GEAR, OVER TOP-----	1-M7	* * * * *					
	1-N8	GEAR, PARKING-----	1-G11						
	2-D6	GEAR, REVERSE-----	1-L7	HANDLE(L), INNER-----	3-I3	HOSE NO. 1, WATER-----	3-C4	IGNITER, IG. COIL-TRALING-----	1-G8
	2-E7	GEAR, REVERSE IDLE-----	1-M7	HANDLE(L), OUT-----	3-I3	HOSE NO. 2, WATER-----	3-C4	INDICATOR-----	2-I8
	2-F6	GEAR, RING-FLY WHEEL-----	1-J3	HANDLE(R), INNER-----	3-H3	HOSE NO. 3, WATER-----	3-C4	INDICATOR, ECONOMY-METER-----	2-E15
	2-F11	GEAR, SHAFT-----	3-D9	HANDLE(R), OUT-----	3-I3	HOSE NO. 4, WATER-----	3-C4	INDICATOR, LEVEL-----	2-H7
	2-G7	GEAR, SMALL SUN-----	1-F11	HANDLE, JACK-----	2-I5	HOSE, AIR-----	1-E5	INJECTION, FUEL-M.P. ELECT-----	1-J4
	2-L6	GEAR, SPEEDO.DRIVE-----	1-M7	HANDLE, SLIDING ROOF-----	3-D6			INSULATOR-----	1-D4
GASKET & SEAL KIT-----	1-L11	GEAR, STATIONARY-FRT-----	1-E3	HANGER-----	2-E6	HOSE, BREATHER-----	2-M6		1-M4
GASKET KIT, COMPRESSOR-----	3-D5	GEAR, STATIONARY-RR-----	1-F3	HANGER, ENGINE-----	1-H3	HOSE, CLUTCH FLEXIBLE-----	2-J6	INSULATOR(L), COWL SIDE-----	3-E10
	3-F5	GEAR, STEERING-----	2-I4	HANGER, ENGINE-REAR-----	1-H3	HOSE, DRAIN-----	2-F8	INSULATOR(L), F.FLOOR-----	3-E10
	1-N3	GEAR, SUN-----	1-E11	HANGER, SILENCER-----	2-E6		3-J4	INSULATOR(R), COWL SIDE-----	3-E10
GASKET NO. 2, IN. MANIFOLD-----	1-C3	GEAR, 1ST-----	1-K7	HANGER, STRAP-----	3-L5	HOSE, DRAIN-REAR-----	3-F6	INSULATOR(R), F.FLOOR-----	3-E10
GASKET SET, ENGINE-----	1-C3	GEAR, 2ND-----	1-K7	HARNES-----	2-K4	HOSE, DRAIN-SUN ROOF FRONT-----	3-E6	INSULATOR, BONNET-----	2-I12
GASKET SET, SUB-ENG-----	1-C3	GEAR, 3RD-----	1-J7	HARNES NO. 2, REAR-----	3-D8	HOSE, EVAPORATION-----	1-I4	INSULATOR, BOOT-----	2-M15
GASKET(C), SPOILER-----	3-E11	GENERATOR, SPEED PULSE-----	3-K6	HARNES NO. 3, REAR-----	3-D8	HOSE, FLEXIBLE-----	2-K7	INSULATOR, CONVERTER-----	2-E6
GASKET(L)-----	2-G11	GLASS(L), DOOR-FRT-----	3-D3	HARNES, BLOWER UNIT-----	3-H4	HOSE, FLEXIBLE-HIGH-----	3-J4	INSULATOR, DASHBOARD-----	3-D10
GASKET(L), REAR SIDE-----	2-L11	GLASS(L), MIRROR-----	3-I10	HARNES, COOLING UNIT-----	3-H5		3-M4	INSULATOR, EX. MANIFOLD-----	1-C4
GASKET(L), SPOILER-----	3-D11	GLASS(R), DOOR-FRT-----	3-D3	HARNES, DASHBOARD-----	3-H8	HOSE, FLEXIBLE-LOW-----	3-J4	INSULATOR, EXH. MANIFOLD-----	1-E4
GASKET(R), REAR SIDE-----	2-L11	GLASS(R), MIRROR-----	3-I10	HARNES, DOOR-DRIVER SIDE-----	3-J8	HOSE, FUEL-----	2-F8	INSULATOR, FRONT-----	2-C14
GASKET(R), SPOILER-----	3-D11	GLASS, BACK WINDOW-----	3-M5	HARNES, DOOR-PASSENGER SI-----	3-J8		1-I4	INSULATOR, FUEL DIST.-----	1-J4
GASKET, A.C.V-----	1-E5	GLASS, FRONT-WARNING UNIT-----	2-F15	HARNES, ENGINE-----	3-G8		2-F8	INSULATOR, HEAT-----	1-E4
GASKET, B.A.C. VALVE-----	1-N5	GLASS, WINDSHIELD-----	3-M5	HARNES, FRONT-----	3-G8		2-G8	INSULATOR, HEAT-FRONT-----	2-C14
GASKET, BLIND COVER-----	1-G7	GRILLE(C), VENTILATOR-----	2-C16	HARNES, INST-----	3-H8	HOSE, MAIN-----	2-N6	INSULATOR, INJECTION-----	1-K4
GASKET, BODY-LWR-----	1-H10	GRILLE(L), DEF. NOZZLE-----	2-H15	HARNES, INSTRUMENT-----	3-H8	HOSE, FUEL MAIN-----	2-F8	INSULATOR, MASTER VAC-----	2-D8
GASKET, BODY-UPP-----	1-H10	GRILLE(L), FENDER-----	2-G12	HARNES, INT. LAMP-----	3-E8	HOSE, FUEL-MAIN PIPE-----	2-F8	INSULATOR, ROD-ANTENNA-----	3-J7
GASKET, CAP-----	2-H6	GRILLE(L), SPEAKER-----	3-L3	HARNES, LOGICAL CONTROL-----	3-E8	HOSE, FUEL-SEPARATOR-----	2-N6	INSULATOR, ROOF-----	3-H9
GASKET, CHAMBER-EXTRACTOR-----	3-B12	GRILLE(R), DEF. NOZZLE-----	2-H15	HARNES, REAR-----	3-D8	HOSE, JOINT-FILLER PIPE-----	2-M6	INSULATOR, SUB-----	1-C4
GASKET, COMPRESSOR-----	3-F5	GRILLE(R), FENDER-----	2-G12	HARNES, SLIDING ROOF-----	3-D6	HOSE, OIL-----	1-F9		1-E4
	3-F5	GRILLE(R), SPEAKER-----	3-K3	HEAD, CYL.-COMPRESSOR-----	3-D5		1-G9		
	1-E8	GRILLE, COWL-----	2-F12	HEADER, FRONT-----	2-I13		1-H6		
GASKET, COVER PLATE-----	3-L6	GRILLE, EXTRACT.-T.S. TRIM-----	3-N9		2-J13		1-I6		
GASKET, DRAIN PLUG-----	1-I10	GRILLE, SPEAKER-----	2-G15	HEADER, REAR-----	2-I13	HOSE, PRESSURE-----	2-K4		
GASKET, DRUM SUPPORT-----	1-K5	GRIP, FRT ASSIST-----	3-L3		3-E4	HOSE, RESERVE-----	2-H6		
GASKET, E.G.R. VALVE-----	1-C4	GROMMET-----	2-H10	HEATER UNIT-----	2-N12	HOSE, RETURN-----	2-K4		
GASKET, EX. MANIFOLD-----	1-M9		2-K10	HINGE-----	2-H12	HOSE, SIDE-DEMISTER-----	2-C16		
GASKET, EXTENSION-----	1-C4	GRILLE, COWL-----	2-F12	HINGE(L), BONNET-----	3-D3	HOSE, SUB TANK-----	1-L6	JACK-----	2-I5
GASKET, EXTENSION-TANK-----	2-L6	GRILLE, EXTRACT.-T.S. TRIM-----	3-N9	HINGE(L), DOOR-LOWER-----	3-D3	HOSE, VACUUM-----	1-I5	JOINT SET, BALL-----	2-J4
GASKET, FILLER PIPE/TANK-----	1-I3	GRILLE, SPEAKER-----	2-G15	HINGE(L), DOOR-UPPER-----	3-D3		2-H7	JOINT SET, INNER-----	2-D3
GASKET, FRONT COVER-----	1-L3	GRIP, FRT ASSIST-----	3-L3	HINGE(L), LID-LAMP-----	2-D11		2-I7	JOINT SET, OUTER-----	2-D3
GASKET, GOVERNOR-----	1-L9	GROMMET-----	2-H10	HINGE(R), BONNET-----	2-H12	HOSE, VENTILATION-----	1-I4	JOINT(L), STRUT BAR-----	2-N12
GASKET, HINGE-LIFT GATE-----	3-K5		2-K10	HINGE(R), DOOR-LOWER-----	3-D3	HOSE, WATER-----	1-I5	JOINT, BACK WINDOW MOULD-----	2-J10
GASKET, IN. MANIFOLD-----	1-N3	GRILLE, COWL-----	2-F12	HINGE(R), DOOR-UPPER-----	3-D3		1-J6	JOINT, BALL-----	3-F6
GASKET, JOINT PIPE-----	2-D6	GRILLE, EXTRACT.-T.S. TRIM-----	3-N9	HINGE(R), DDOR-UPPER-----	2-D11		1-K6	JOINT, DRAIN HOSE-REAR-----	3-E6
GASKET, JOINT PIPE-----	2-M11	GRILLE, SPEAKER-----	2-G15	HINGE, GLASS HATCH-----	3-K5	HOSE, WATER SUB TANK-----	1-K6	JOINT, FUEL PIPE-----	2-L7
GASKET, LICENSING-----	1-D3	GROMMET-----	2-H10	HOLDER SET, THROTTLE BODY-----	1-C5	HOSE, WATER-T/C WATER-PIPE-----	1-E4	JOINT, HOSE-----	3-E9
GASKET, METERING OIL-----	1-D3	GROMMET, ACTUATOR-----	3-F7	HOLDER, BONNET STAY-----	2-H12	HOSE, WATER-TURBOCHARGER-----	1-E4		3-L8
GASKET, OIL CAP-----	1-O3	GROMMET, REAR COOLER-----	3-N4	HOLDER, BONNET STAY-SHROUD-----	1-N8	HOUSING SET, BRG WATER PUM-----	1-I6		1-E3
GASKET, OIL FILLER PIPE-----	1-E3	GROMMET, REAR FLOOR-----	2-N13	HOLDER, BRUSH-----	2-J6	HOUSING(L), BACK UP LAMP-----	2-K11		2-H6
GASKET, OIL PAN-----	1-M9	GROMMET, SCREW-----	2-E10						
GASKET, OIL PIPE-----	1-F4		2-F12						
GASKET, OIL PUMP-----	1-E9		2-I11						
GASKET, OIL STRAINER-----	1-C6		2-M11						
GASKET, SOLENOID VALVE-----	1-J5								

MODEL IDENTIFICATION

This parts catalog has been compiled to cover the following models.

(1/1)

Model No.	Specifications of vehicles																				VIN (Chassis No.)				
	Basic spec.	Eng line	Turbo	T/mission	Speed		Body	Roof	Suspension	Diff.	Brake	Air bag	Production period	Model year	California & Federal			Guam & Saipan							
	U.S.A.	RE 13B	Turbo	Manual Transmission	Automatic Transmission	4 speed	5 speed	Coupe	W/O sun roof	Sun roof	Normal suspension	Hard suspension	Limited slip diff.	A. lock brake	Air bag	From	To	1993	Production for California & Federal	Grade		Production for Guam & Saipan	Grade		
	(US)	(13)	(TR)	(MT)	(AT)	(4S)	(5S)	(CP)	W/O SR	(SR)	(NS)	(HS)	(LS)	(AL)	(AB)	Dec '91	Aug '93	→	Yes	(BS)		(R1)	(TR)	Yes	(BS)
FD01	US	13	TR	MT		5S	CP	W/O SR		SR	NS	LS	AL	AB	Dec '91	Aug '93	→	Yes	BS		Yes	BS			FD3+++ - 200001-300000
FD02	US	13	TR		AT	4S	CP	W/O SR			NS	LS	AL	AB	Dec '91	Aug '93	→	Yes	BS		Yes	BS			FD3+++ - 200001-300000
FD03	US	13	TR	MT		5S	CP	W/O SR			HS	LS	AL	AB	Dec '91	Aug '93	→	Yes		R1	Yes		R1		FD3+++ - 200001-300000
FD04	US	13	TR	MT		5S	CP		SR		NS	LS	AL	AB	Dec '91	Aug '93	→	Yes			TR	Yes		TR	FD3+++ - 200001-300000
FD05	US	13	TR		AT	4S	CP		SR		NS	LS	AL	AB	Dec '91	Aug '93	→	Yes			TR	Yes		TR	FD3+++ - 200001-300000

BODY PAINTS AND INTERIOR COLORS

THIS LIST SHOWS COMBINATION OF BODY PAINT AND INTERIOR COLOR. USING THIS LIST YOU WILL BE ABLE TO FIND OUT NECESSARY COLOR CODE OF PART YOU NEED IN THE TEXT.

BODY PAINT		INTERIOR COLOR CODE		
NAME	CODE			
Competition yellow	J9	F E 2		
Montego blue metallic	M8	F E 2	F E 3	
Vintage red hiref cort	NT	F E 2	F E 3	
Vintage red	NU	F E 2	F E 3	
Brilliant black hiref cort	PX	F E 2	F E 3	F E 4
Brilliant black	PZ	F E 2	F E 3	F E 4
Crystal white	UC	F E 2	F E 3	F E 4
Montego blue mica hiref cort	2A	F E 2	F E 3	
Silver stone metallic	3L	F E 2		F E 4
Silver stone metallic hiref cort	4G	F E 2		F E 4

NOTE
COLORS OF INTERIOR CODES
ARE AS FOLLOWS.

FE2	Black
FE3	Tan
FE4	Red

COMPLETE ASSEMBLY PARTS NUMBERS

Engine

Specifications of vehicles		Parts number
T/mission	Suspension	
Manual T/mission	Normal	N3A5 - 02 - 000
	Hard	N3A1 - 02 - 000
Automatic T/mission	※	N3A2 - 02 - 000

Cabin

(1/1)

Specifications of vehicles		Parts number
Roof	Suspension	
W/O sun roof	Normal	FD01 - 07 - 000
	Hard	FD03 - 07 - 000
Sun roof	※	FD04 - 07 - 000


T/mission

Specifications of vehicles	Parts number
T/mission	
Manual T/mission	R564 - 03 - 000
Automatic T/mission	BV65 - 19 - 090G

The ※ mark in the above chart does not affect on part number selection.
Complete assemblies are available and manufactured in accordance with current production specifications only.

VEHICLE IDENTIFICATION SYSTEM FOR RX-7 SERIES (1993)

VIN (= Vehicle Identification Number) for RX-7series (1993 Year Model) consists of WMI(= World Manufacturer Identifier), VDS(= Vehicle Description Section) and VIS(= Vehicle Identification Section). VDS consisting of six alphanumeric characters denotes the "MODEL SERIES". VIS consisting of eight alphanumeric characters denotes the serial unit number of vehicle and is sequentially numbered within each VDS.




* Check digit is included as a VIN security feature to permit law enforcement verification of the authenticity of a suspected illegal VIN plate. This single digit number is determined, based upon a complex mathematical formula which is applied to each vehicle's VIN number.

** Miscellaneous Identification Code identifies major components such as engine, brake system, cab type, etc.

LOCATION OF VIN PLATE

The plate is attached to the top ledge of the dash panel under the bonnet(engine hood), refer to the illustration shown right.



(Note)

If the VIN(Chassis) reference number in the PCM(Parts Catalog Microfiche) appeared as:

FD3 *** - 200001

...the vehicle's VIN would be e.g. JM1FD331*P0200001.

ABBREVIATIONS

The following abbreviations are used throughout Mazda Microfiche parts catalog: in the illustration, text, section number index, alphabetical index.

Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition
1ST	First	B.S.V.	Bleed Solenoid Valve	DIFF	Differential	H	Head	L/EM	Loss Emission Controls	P	Panel
2ND	Second	BTHR	Breather	DISC/B	Disc Brake	HARN.	Harness	L.H.D.	Left Hand Drive	(P)	Primary
2D.	2-Door	BUMP	Bumper	DIST	Distributor	H.A.C.	High Altitude Compensator	LH SIDE	Left Hand Side	PARK or PARKG	Parking
2-SEAT	2-Seater	BURG.	Burglar	DMPR	Dumper	H.A.COMPENSATOR	High Altitude Compensator	LKOUT	Lockout	PASS.	Passenger
3D.	3-Door	BY A.C.V.	Bypass Air Control Valve	DOHC	Double Overhead Camshaft	H.B.	Hatchback	L.NOSE	Long Nose	P.B.	Proportioning Brake
3RD	Third	[C]	Center	D.P.	Dual Proportioning	H.B. RE	Hatchback Release	LNVGT. CPU	Loss Navigation Computer	P.C.V.	Positive Crankcase Ventilation
3-SP	3-Speed	C. or (C)	Center	DRUM/B	Drum Brake	HC-AT	Hydro Control Automatic T/Mission	LO	Low	PHILPNS	Philippines
4D.	4-Door	CALIF.	California	D/TIRE or D.TIRE	Double Tire (-Dual Tire)	HIGHT	High Tension	L.S. VALVE	Load Sensing Valve	PILR	Pillar
4-SP or 4 SPD	4-Speed	C/AREA	Cold Area	D.T. TOP	Detachable Top	HIDUTY	Heavy Duty	L/PARTITION	Less Partition	PIV	Pivot
4.5-SP	4-Speed 5-Speed	CAN.	Canada	DRUMP	Dump Truck	HEA. or HEAT.	Heater	L.P.G.	L.P. Gas (=Liquefied Petroleum Gas)	PKG.	Package
4TH	Fourth	CARB.	Carburetor	DX.	Deluxe	HL -	High -	L.S.D or L.S. DIFF	Less Slip Differential	PNEUMA.	Pneumatic
5D	5-Door	CAT	Catalyst	D. YLW	Dark Yellow	HIAI TI	High Altitude Head Injury Criteria	..LITER(s) TANK	..Liter(s) Tank	PNL	Panel
5-LINK	5-Link Suspension	C.DISC	Compact Disc Conventional Engine (-Reciprocating Gasoline Engine)	DI	Direct Injection	HIGHT	High-Tension	L/TAILGATE	Less Tailgate	PNT	Point
5-SP or 5-SPD	5-Speed	CE	Constant Gear Ratio Coach	ECE	Economic Commission for Europe	H.I.C.	Head Injury Criteria	LVR	Lever	POSI.	Position
10TH-ANNIV	10th Anniversary	C.U.R.	Constant Gear Ratio Coach	ECON.	Economy	HL or H.L. or HLAMP	Head Lamp	LWR	Lower	POSIT.	Positive
[A]	.Amps	CH	Change	E.C.P.S. SYS	Electric Control Power Steering System	H.KONG	Hong Kong	LRG.	Large	POW. WINDOW	Power Window
.A	.Amps	CHG	Change	EGI	Electric Gasoline Injection	HNGR	Hanger	LX-P	LX with Performance Package	P.P.	Polypropylene (Plastics)
A.A.S. or A.A. SUSP	Automatic Adjustment Suspension	CHMBR	Chamber	ELECT	Electric	.HP	..Horsepower(s)	[M]	..Meter(s)	PRESS	Pressure
ABS.	Absorber	CHK	Check	E.M.	Energy	H.P.R.	High Penetration Resisted	.M	..Meter(s)	PROTN	Protection
A.B.S.	Anti lock Brake System	CLG.	Cooling	ENEGY or ENGY	Energy	HSG	Housing	MA. CYL	Master Cylinder	PROTR	Protector
A.B.S.V.	Air Bleed Solenoid Valve	CLNR	Cleaner	ENG.	Engine	HT, HET or HTOP	Hardtop	MAINT.	Maintain or Maintenance	PORTGL	Portugal
A.C.	Air Conditioner	CLTR	Cigarette Lighter	ENQ.	Engine	HWI	Neutral	MAP	Manifold Absolute Pressure	P.S.	Power Steering
A.C.C.	Automatic Cruise Controls	CM	..Centimeter (s)	EOLZR	Equalizer	[I]	Inner Diameter	M.A. SUSP	Multi-Adjustable Suspension	P.SOUND	Premium Sound
ACCEL.	Accelerator	C.MEMBER	Crossmember	EQUIP.	Equipment	IG or IGH.	Ignition	M.EAST	Middle East	PSTN	Postion
ACTR	Actuator	CNTNR	Container	EX.	Exhaust	IL	Island	M.F	Maintenance Free	PTC	Positive Temperature Coefficient
A.C.V	Air Control Valve	CCMB	Combustion	EXC.	Except	ILLUM.	Illumination	M. EAST	Middle East	P.T.O.	Power Take Off
ADJ.	Adjuster or Adjustable or Adjusting	COMP.	Compass	EXC. 10TH-ANNIV.	Exc. 10th Anniversary	IN.	Inlet	M.F	Mirror	PU	Pickup
ADJ.SUSP	Adjustable Suspension	COMPR	Compressor	EXT.	Extractor	IND.	Indicator	M.L	Mainland	PW or P. WINDOW	Power Window
AIR P.	Air Pipe	CONDNSR	Condenser	EXTRACT.	Extractor	INHIB.	Inhibitor	MLD. or MLDG.	Moulding	PWRGT LIF. R	Power Gate Lifter
AIR CON	Air Conditioner	CONN.	Connector or Connecting	(F)	Fr... (Foot)	INJ.	Injection	MM	..Millimeter(s)	PWT	Powertrain
ALTR	Alternator	CONS.	Console	F. -	Fr... (Foot)	INN.	Inner	M.P.	..Millimeter(s)	[Q]	Quarter
ALUMI.	Aluminum	CONT.	Control	FED.	Federal	INS.	Insulation	M.P.	..Millimeter(s)	QTR.	Quarter
AMP.	Amplifier	CONV.	Conventional	FINIS	Finisher	INSP.	Inspection	MT	Mounting	QTY	Quantity
ANALOG	Analogue	CONVR	Converter	F.I.P.	Fuel Injection Pump	INST.	Instrument	MT	Mounting	[R]	..R or (R)
ANNIV.	10th Anniversary	COVR	Cover	FLEX	Flexible	INT.	Interior	MT	Mounting	R.	..R or (R)
ANT	Antenna	CPE	Coupled	F.I.MIXER	Fuel Injection Mixer	INT. COOLER	Inter Cooler	MT	Mounting	RE	Rotary Engine
ARG	Argent	CPT.	Complete Assembly	FX.	Fixing	INTERM.	Intermediate	MARR.	Narrow	RECIPRO	Reciprocating Engine (=Conventional Engine)
A.S. ABSORBER	Adjust Shock Absorber	CPU	Computer	F.L.DICK	Fuel Logic Deck	INTMT. or INTERMIT.	Intermittent	H.C.	Normal Close	REFRIGER	Refrigerator Van
ASH	Ashtray	CRK	Crank	FOLD.	Folding	I.R.S. or LR. SUSP	Independent Rear Suspension	N.O.	Normal Open	REC. or REGU.	Regular
ASSY	Assembly	CRUST	Crusher	FRA	France	I.S.C.	Idle Speed Control	NO.	Number	REG. GAS	Regular Gasoline
AT	Automatic Transmission	C/SHIFT	Column Shift	FRT	Front	IVRY	Ivory	NON-SP	Non-Special Equipment	REGUL.	Regulator
ATT	Attachment	CUSH.	Cushion	FULL CCLN.	Fully Controlled	[K]	..Kilogram(s)	NON-TILT	Non-Tilting	REL	Normal
AUS	Austria	CYL	Cylinder	[Q]	..Gram(s)	[K]	..Kilogram(s)	NOZ.	Nozzle	REM. CON.	Remote Controlled
AUST.	Australia	[D]	Door	[G]	..Gram(s)	[K]	..Kilogram(s)	N.S.W.	New South Wales (Aust.)	RET	Return
AUTO.	Automatic	D. or DR	Door	GARN	Garnish	[L]	..Kilowatt(s)	NVGT. CPU	Navigation Computer	RETRAC	Retractable
[B]	Balance	D..	Diameter...	GAS.	Gasoline	L or (L)	Left	N.Z.	New Zealand	REV.	Reverse
BAL.	Ball	DBI CAB	Double Cab (=Crew Cab)	GASOH	Gasohol	L	Length =	R.H.D	Right Hand Drive	RICO	Rubber
BAT	Battery	D. BLUE	Dark Blue	GEN	General	.L	..Liter(s)	R.H. SIDE	Right Hand Side	REINFORC	Reinforcement
B.COLOR	Body Color	D. BRN	Dark Brown	G.HATCH	General Hatch	.L	..Liter(s) Tank	O.FLTR	Oil Filter	R	Rear
B.DOOR	Back Door	DE	Defroster	GLD. M	Gold Metallic	.L	..Liter(s) Tank	O.H	Over Head	R or RR	Rear
BDY	Body	DEF.	Defroster	GLS	Glass	U.A.A. SUSP	Less Automatic Adjusting Suspension	OH	Overhead Camshaft	[S]	Side
BELT.	Beltline	DEFG	Defogger	GOV.	Governor	U.A.C.	U.A.C. Body	OIL CONSUMP	Oil Consumption	S	Side
BLK	Black	DES	Design	GRN	Green	U/BODY	U/BODY	OP	Optional	[S]	Secondary
BLU	Blue	DEMBST.	Demister	GRY	Grey	U/BOX	U/BOX	ORD. BY.	Order By.	SAFE	Safety
BLU/GRY	Bluish Gray	D. GRY	Dark Gray	GRYGRN	Greish Green	U/CPMT	Luggage Compartment	O.S.	Oversize	S. AFRICA	South Africa
BLU. M	Blue Metallic	DAHP	Diaphragm	[N]	..Gram(s)	L.C.DISPLAY	Liquid Crystal Display	O.T.	Over Top	SAUDI	Saudi Arabia
BLVA	Bolevia					[L]	Less Electric Gasoline Injection	OUT.	Outer	S.BODY	Short Body
BRG.	Bearing					[L]	Less Electric Gasoline Injection	[P]	Panel	S.BOX	Short Box
BRKT.	Bracket										
BRN.	Brown										
BRT	Britan (=Great Britain)										

Abbreviation	Definition	Abbreviation	Definition	Abbreviation	Definition
SDN	Sedan	U LONG	Ultra Long		
S.DUTY	Standard Duty	UND	Under		
SELECT	Selective Use	UP	Upper		
SEN	Sensor	URETANE	Urethane Rubber		
SERV	Service	U.S	Undersize		
S FORK	Shift Fork	[V]	Volt(s)		
SG, SQN or SIG	Signal	V	Valve		
SHFT	Shift	VAC	Vacuum		
SHRD	Shroud	V CHAMBER	Vacuum Chamber		
SHTR	Shutter	Vent	Ventilator or Ventilation		
SILV M or SILVER M	Silver Metallic	V.G.R.	Variable Gear Ratio		
SING	Singapore	VNL	Very!		
SP.2H	Speaker	[W]	Watt(s)		
SLN	Saloon	W	Window		
SML	Small	W or WIND	Width		
S. NOSE	Short Nose	W-	With or Like with		
SOL	Solenoid	W/O L.S. VALVE	W/O Load Sensing Valve		
SP	Speed	W/O ORL CONSUMP	W/O Oil Consumption		
SPEC	Specification	W/O P T O	W/O Power Take-Off		
SPEEDO	Speedometer	WARN	Warning		
SPG	Spring	WAS	Washer		
SPK	Speaker (- Loud-speaker)	W/AUTO BELT	With Automatic Shoulder Belt		
SPLR	Spooler	W CHASSIS	Windshield Chassis		
S1	Steering	WAT	Water		
STAB	Stabilizer	WGN	Wagon		
STD	Standard	WHL	Wheel		
S.TIRE or S. TIRE	Single Tire	WHT	White		
STYL	Stylet	WIND	Window		
SUB-TRNS	Sub-transmission	WIP	Wiper		
SUN SHLD	Sun Shield	W/O AUTO BELT	Without Automatic Shoulder Belt		
SURGT.	Surge Tank	W/O.	Without		
SUP GAS	Super Gasoline	WOOF	Wooler		
SUSP	Suspension	W PUMP	Water Pump		
S.V	Solenoid Valve	WSHLD or WINDSHLD	Windshield		
SW	Switch	WSTR or WTHSTP	Weatherstrip		
S. WASHER	Screen Washer (Windshield Washer)	W/T	With Tube (Tire)		
SWD.	Sweden	[Y]	Yellow		
SYNC	Synchronizer	YLW	Yellowish Green		
[T]	Ton(s)	YLW/GRN	Yellowish White		
.T	Thickness	YLW/WHT	Yellowish White		
TACH & TACHOM	Tachometer	[Z]	Zone Temperature		
T.ADJUST	Time Adjusting				
TACHOM TACHOM.	Tachometer				
T.BELT	Timing Belt				
T.CEILING	Top Ceiling				
TEMP.	Temperature				
T/F	Transfer				
TH	Throttle				
THAI	Thailand				
THERM.	Thermostat				
THROT.	Throttle				
T/L	Tubeless				
T.MISSION	Transmission				
TRD CLMT	Tropical Climates				
TRK	Truck				
TRQ. GLIDE	Torque Glide				
T. TOBAGO	Trinidad and Tobago				
TURB	Turbocharge				
TWN	Twin				
[U]	The United Kingdom				